



# INSTALLATION AND MAINTENANCE INSTRUCTIONS

HYBRID SYSTEM WITH AIR TO WATER HEAT PUMP

## GREENSTAR PLUS HYBRID

FOR COMBINATION WITH WORCESTER APPLIANCES THAT HAVE A CENTRAL HEATING OUTPUT UP TO 28kW



6720803687-00.1Wo



**TABLE OF CONTENTS**

<b>1</b>	<b>Key to symbols and safety instructions</b>	<b>4</b>	5.2.6	Hybrid manager	21
1.1	Explanation of symbols	4	5.2.7	External unit	21
1.2	Safety instructions	4	5.3	Pre-installing pipes	24
<b>2</b>	<b>About the appliance</b>	<b>5</b>	5.3.1	Preparing the hybrid manager connection	24
2.1	Designated use	5	5.3.2	Fitting the bypass valve	24
2.2	EU Declaration of Conformity	5	5.3.3	Mounting the FW200 programming unit	24
2.3	Data plate	5	5.4	Mounting the hybrid manager	24
2.4	Standard delivery	6	5.5	Installing the external unit	25
2.5	Accessories	6	5.5.1	Preparing the condensate drain for the external unit	26
2.6	Tools, materials and miscellaneous parts	6	5.5.2	Mounting on foundations	26
2.7	General information on energy use and heat production	6	5.5.3	Making a condensate drain for the external unit	26
2.8	Function description of the hybrid manager	7	5.6	Installing the refrigerant circuit	27
2.9	Handling circuit boards	7	5.6.1	Safety	27
2.10	Refrigerant circuit	8	5.6.2	Preparing for installation	27
2.11	Combi boiler with serial buffer tank, bypass valve and unmixed heating circuit	9	5.6.3	Routing refrigerant lines	27
2.12	System boiler with serial buffer tank, bypass valve and unmixed heating circuit	10	5.6.4	Connecting the hybrid manager	27
2.13	Combi boiler with serial buffer tank, bypass valve, unmixed heating circuit and independently controlled mixed heating circuit	11	5.6.5	Connecting the external unit	28
2.14	System boiler with serial buffer tank, bypass valve, unmixed heating circuit and independently controlled mixed heating circuit	12	5.6.6	Checking the refrigerant circuit for tightness	28
2.15	Overview of components	13	5.6.7	Insulating the refrigerant shut-off valve	29
2.15.1	Greenstar Plus hybrid manager (internal unit)	13	5.6.8	Evacuating and drying the refrigerant circuit	29
2.15.2	Greenstar Plus hybrid external unit	14	5.7	Making the electrical connection	30
2.16	Dimensions	16	5.7.1	Safety	30
2.16.1	hybrid manager (internal unit)	16	5.7.2	General requirements	30
2.16.2	external unit	17	5.7.3	Connecting the external unit	30
2.17	Technical Data	18	5.8	Installing the outside temperature sensor	31
2.17.1	Hybrid system	18	5.8.1	Select the installation location	31
2.17.2	Hybrid manager	18	5.8.2	Connecting the outside temperature sensor	32
2.17.3	External unit	18	5.9	Setting the DIP switches of the external unit	32
<b>3</b>	<b>Regulations</b>	<b>19</b>	<b>6</b>	<b>Commissioning</b>	<b>32</b>
3.1	Standards, regulations and guidelines	19	6.1	Before commissioning	32
3.1.1	General regulations	19	6.1.1	Safety	32
<b>4</b>	<b>Transport</b>	<b>19</b>	6.1.2	Commissioning requirements	32
4.1	Lifting and carrying the external unit	19	6.2	Commissioning the system for the first time	33
4.2	Unpacking the external unit	19	6.2.1	Providing the external unit with a power supply ahead of commissioning	33
4.3	Unpacking the hybrid manager	20	6.2.2	providing the external unit with a power supply during commissioning	33
4.4	Checking the delivery	20	6.2.3	Connecting the CANBUS cable to the hybrid manager unit	33
<b>5</b>	<b>Mounting and installation</b>	<b>20</b>	6.2.4	Making the power supply connection	33
5.1	Preparing for installation	20	6.2.5	Switching on the hybrid system	33
5.1.1	Cleaning primary systems	20	6.2.6	Connecting the programming unit to the hybrid control module	34
5.2	System component configuration	21	6.2.7	Connecting the heat source to the hybrid manager	34
5.2.1	General requirements	21	6.2.8	Communication error from External unit on initial power ON of External Unit and Hybrid Manager	34
5.2.2	Buffer tank	21	6.2.9	Adjusting the Hybrid manager circulating pump in the hybrid manager	35
5.2.3	Bypass valve	21	6.2.10	System with series buffer tank	35
5.2.4	Expansion vessel	21	6.2.11	Venting the hybrid manager	38
5.2.5	Thermostatic radiator valves	21	6.2.12	Setting the bypass valve	38
			6.2.13	Setting parameters for optimising energy use and costs of the hybrid system	38
			6.2.14	Explanation of the parameters for energy and cost optimization of the hybrid system (control strategy)	39
			6.2.15	Control Strategy: Option CO2 Optimised and co2 :cost mix	41

6.2.16 Control Strategy: Co2 optimised (environmental factors)	41	10.2.8 DC fan motors/check PCB	71
6.2.17 Control Strategy: CO2: Cost mix	42	10.2.9 Check external unit temperature sensor	72
6.2.18 Control Strategy: Option changeover temperature	42	10.2.10 Check linear expansion valves (LEV)	74
6.2.19 Control Strategy: Cost optimised	42		
6.2.20 Control strategy: hydraulic connection	42	<b>11 Replace components</b>	<b>76</b>
6.2.21 Control strategy: Delay time for boiler heating	43	11.1 Pumping refrigerant back into the external unit	76
6.2.22 Control strategy: Temperature diff for boiler switch ON	43	11.2 Removing the casing from the external unit	77
6.2.23 Setting parameters at the hybrid control module	44	11.3 Replacing the fan motor	78
6.2.24 Commissioning of the air to water heat pump at outside temperatures outside the standard operating range	46	11.4 Replacing the PCB housing	79
6.2.25 Informing the customer and handing over the technical documents	46	11.5 Replacing PCBs	79
		11.5.1 Noise circuit board	79
<b>7 Operation</b>	<b>46</b>	11.5.2 Power circuit board	79
7.1 Automatic defrost function	46	11.5.3 Controller circuit board	79
7.2 System shutdown	46	11.6 Replacing faulty temperature sensors TH3, TH6 or TH33	79
7.2.1 Regular system shutdown	46	11.7 Replacing outside temperature sensor TH7	79
7.2.2 System emergency shutdown	46	11.8 Replacing temperature sensors TH4 and TH32	79
7.3 Restarting the hybrid system after an interruption in operation	47	11.9 Fitting and removing the linear expansion valve	80
		11.10 Removing the transformer (ACL)	80
<b>8 Environmental protection/disposal</b>	<b>47</b>		
8.1 Disposing of refrigerant	47	<b>12 Filling the refrigerant circuit</b>	<b>80</b>
8.2 Appliance disposal	47	12.1 Evacuating and drying the refrigerant circuit	81
		12.2 Vacuum drying	81
<b>9 Inspection and maintenance</b>	<b>47</b>	12.3 Opening the shut-off valves of the external unit	81
9.1 Preparing for inspection and maintenance	47		
9.2 Enter into an inspection and maintenance contract	48	<b>13 Appendix</b>	<b>82</b>
9.3 Maintenance intervals	48	13.1 Cost weighting electricity price—gas price	82
9.4 Maintaining the hybrid manager	49	13.2 System wiring (heatronic III boiler connections) with a bypass valve and one unmixed heating circuit	83
9.4.1 Visual inspection of the hybrid manager	49	13.3 System wiring (CUS boiler connections) with a bypass valve and one unmixed heating circuit	84
9.4.2 Draining the heating water from the hybrid manager	49	13.4 Wiring to PCB in the external unit (heat pump)	85
9.4.3 Cleaning the filter	49	13.5 Controller circuit board in external unit	87
9.4.4 Checking the temperature sensor	50	13.6 Alternative pipe work lengths and DT	89
9.4.5 Completing inspection and maintenance	50		
9.5 Servicing the external unit	51	<b>14 General details</b>	<b>90</b>
9.5.1 General notes	51		
9.5.2 Visual inspection of external unit	51	<b>15 Assembly and installation report for the installer</b>	<b>92</b>
9.5.3 Cleaning the external unit air intake	51		
9.5.4 Completing inspection and maintenance	51	<b>16 Commissioning report for the commissioning engineer</b>	<b>94</b>
9.5.5 Overview of DIP switches in the external unit	52		
9.6 Inspection and maintenance reports	53		
<b>10 Faults</b>	<b>54</b>		
10.1 Faults that are not displayed	54		
10.1.1 General faults	54		
10.1.2 External unit faults—frequently asked questions	54		
10.2 Displayed faults	55		
10.2.1 Fault displays on the hybrid control module	55		
10.2.2 Check temperature sensor of hybrid manager	56		
10.2.3 Faults of the FW200 programming unit	57		
10.2.4 Fault display on the FW 200 weather-compensated controller at user level	57		
10.2.5 Fault display on the rear of the hybrid manager	59		
10.2.6 External unit faults	60		
10.2.7 Check components	70		

# 1 KEY TO SYMBOLS AND SAFETY INSTRUCTIONS

## 1.1 EXPLANATION OF SYMBOLS

### WARNING SYMBOLS

	Safety instructions in this document are framed and identified by a warning triangle which is printed on a grey background.
---	---

	Electrical hazards are identified by a lightning symbol surrounded by a warning triangle.
---	---

Signal words indicate the seriousness of the hazard in terms of the consequences of not following the safety instructions.

- **NOTICE** indicates possible damage to property or equipment, but where there is no risk of injury.
- **CAUTION** indicates possible injury.
- **WARNING** indicates possible severe injury.
- **DANGER** indicates possible risk to life.

### IMPORTANT INFORMATION

	Notes contain important information in cases where there is no risk of personal injury or material losses and are identified by the symbol shown on the left. They are bordered by horizontal lines above and below the text.
--	---

### ADDITIONAL SYMBOLS

Symbol	Meaning
▶	a step in an action sequence
→	a reference to a related part in the document or to other related documents
•	a list entry
–	a list entry (second level)

Table 1

## 1.2 SAFETY INSTRUCTIONS

### HANDLING REFRIGERANT

The air to water heat pump is filled with R410A refrigerant.

- ▶ Only qualified and authorised refrigeration engineers may work on the refrigerant circuit.
- ▶ For all work with refrigerant, wear suitable safety gloves and goggles.

### WHAT TO DO IF REFRIGERANT LEAKS

If refrigerant leaks and touches the skin, it can cause frostbite.

- ▶ In case of a refrigerant leak, never touch any part of the air to water heat pump.
- ▶ Avoid skin or eye contact with refrigerant.
- ▶ Seek medical attention if you get refrigerant on your skin or in your eyes.

### DANGER THROUGH ELECTRICAL CURRENTS

- ▶ Electrical work must only be carried out by competent person. Work on the electrical system that has not been carried out properly can result in short circuit, overheating or fire.

### DANGER POSED BY EXPLOSIVE AND EASILY FLAMMABLE MATERIALS

- ▶ Never use, store or place highly flammable materials (paper, clothing, thinners, paints etc.) near the external unit.

### SITING AND INSTALLATION

Correct siting, assembly and installation of the individual components are the fundamental requirements for safe and economical operation of the hybrid system.

- ▶ Installation of this heat pump should be done in accordance with MCS/MIS 3005.

### COMMISSIONING

- ▶ The hybrid system and the components may only be commissioned by a competent person.

### INSTRUCTING THE CUSTOMER

- ▶ Explain to customers how the hybrid system and its individual components work, and instruct them how to operate them.
- ▶ Inform customers that they must not carry out any modifications or repairs.
- ▶ Hand customers the installation and operating instructions for safekeeping.

### RISK OF DAMAGE DUE TO OPERATOR ERROR

Operator errors can result in injury and damage to property.

- ▶ Ensure that children never operate this appliance unsupervised or play with it.
- ▶ Ensure that only personnel who can operate this appliance correctly have access to it.

### INSPECTION, MAINTENANCE AND REPAIRS

- ▶ Inspection, maintenance and repairs must only be carried out by competent persons.
- ▶ Use only original Worcester spare parts. Losses caused by the use of parts not supplied by Worcester are excluded from the Worcester warranty.
- ▶ Only use accessories intended for this application.
- ▶ **Customer recommendation:** Arrange an annual service with a competent person.

### ENVIRONMENTAL PROTECTION

- ▶ At the end of the appliances life time span please ensure that the effected appliance is disposed of according to the current regulations.
- ▶ Dispose of the packaging materials in an environmentally responsible manner.

### HEAT EMITTERS

- ▶ It is important a hybrid system is installed on a system with the appropriate heat emitters for the combination of a heat pump and boiler.
- ▶ It is recommended a pre-design assessment is carried out to determine the suitability of the system and heat loss calculations for the property are carried out to determine the system design requirements.
- ▶ If under floor heating is installed the system should be correctly sized to work at lower temperatures.

## 2 ABOUT THE APPLIANCE

### 2.1 DESIGNATED USE

The appliance may only be installed in sealed unvented hot water central heating systems to EN 12828. Any other use is considered improper. Any damage that may result is excluded from liability. The commercial and industrial use of the appliance for generating process heat is not permitted.

- Use the appliance exclusively for the stated purpose whilst adhering to the specification and environmental conditions (→ chapter 2.17).
- The following gas condensing boilers can be used in the hybrid system:
  - Greenstar 29, 34, 38 & 42 CDi Classic Combi
  - Greenstar 25 & 30Si
  - Greenstar Highflow 440CDi & 550CDi
  - Greenstar 28, 32 & 36CDi Compact
  - Greenstar 30CDi System Classic
  - Greenstar 12, 15, 18 & 24i System
- Operate the appliance exclusively with R410A refrigerant.
- Take into account the data on the system component data plates.
- Maximum output of the system is 25kW at delta T of 20K. For higher output appliances see table 51 page 89.

Correct use includes adherence to maintenance and inspection intervals.

The hybrid system must not be used for purposes other than those specified. The manufacturer accepts no liability for losses arising from improper, incorrect or unreasonable use.



Observe requirements when using the air to water heat pump (external unit) near buildings with sensitive or interference-prone electronics.

### 2.2 EU DECLARATION OF CONFORMITY

The design and operation of this product conforms to the European Directives and the supplementary national requirements. Its conformity is demonstrated by the CE designation.

### 2.3 DATA PLATE

The data plate includes details of the serial number, appliance performance and approval data.

The hybrid manager Fig. 1 has two data plates, one on the lower right hand side panel of the outer casing [A], and one permanently affixed to the main body of the appliance, on the arms of the control module retainer [B].

The external unit Fig. 2 includes a data plate [D] and an EPHA conformity label [C], these are located, on the lower right front of the external unit.




Fig. 1 Data plates on the hybrid manager (internal unit)

- [A] Cover data plate
- [B] Superstructure data plate
- [1] Unit data
- [2] Serial number




Fig. 2 Data plate on the external unit

- [C] EPHA conformity label (European heat pump association)
- [D] External unit data plate
- [1] Unit data

## 2.4 STANDARD DELIVERY

System components are supplied ready assembled.




Fig. 3 Standard delivery Greenstar Plus Hybrid

- [1] Hybrid manager (internal unit)
- [2] Mounting plate
- [3] Greenstar Plus external unit
- [4] Bag containing the manuals, drawings and small parts

## 2.5 ACCESSORIES



Here you will find a list of typical accessories. Our general catalogue provides a comprehensive overview of all available accessories.

### REQUIRED ACCESSORIES

The system operation requires the following accessories:

- FW200 programming unit with outdoor sensor unit.
- Buffer tank
- Bypass valve.

### OPTIONAL ACCESSORIES

- Wall mounting bracket for wall mounting the external unit including anti-vibration mounts
- Floor bracket with anti-vibration mounts for raised siting of the external unit

- Drain plug kit (including pre cut insulation for service connections)
- Condensation catch pan
- Trace heating element to prevent freezing of water in the catch pan
- Refrigerant pipe ¼ " and ½ " OD

## 2.6 TOOLS, MATERIALS AND MISCELLANEOUS PARTS

Servicing the Hybrid Manager module requires standard tools as used by heating system installers and those for gas and water installations.

## 2.7 GENERAL INFORMATION ON ENERGY USE AND HEAT PRODUCTION

Buildings can be heated efficiently with condensing boilers and air to water heat pumps. However, these two technologies have different performance characteristics.

Condensing boilers as well as air to water heat pumps use energy gained from fossil fuels. In condensing boilers, gas is burnt directly inside the appliance.

Air to water heat pumps use electrical energy which has been obtained from a number of different sources. This includes fossil fuel burning power stations. These are typically around 40 % efficient in converting fuel to useful electricity. Although an air to water heat pump is far more efficient than a condensing boiler at converting its input energy (electricity) into heat, the electricity used has a larger amount of fossil fuel consumption attached. This consumption of fossil fuels is referred to as the primary energy factor (PEF).

The PEF of electricity is generally 2.3, the PEF of oil and gas is 1.1, the PEF of mixed electric power 2.6. The coefficient of performance (COP) of an air to water heat pump is, subject to outside air temperature and water flow temperature, between 2 and 5.5.

Depending on the current situation and heat demand, either the condensing boiler or the air to water heat pump may offer a more favourable energy-to-cost ratio.

The hybrid package integrates both technologies in one system and thereby offers the opportunity to use either heat source optimally at any time. Users can decide for themselves whether the emphasis should be on primary energy consumption and/or whether costs take priority, alternatively, a combination of primary energy and costs can be used.

## 2.8 FUNCTION DESCRIPTION OF THE HYBRID MANAGER

The hybrid control module monitors the external unit, the condensing boiler and the FW200 programming unit. Subject to outside temperature, heating water flow and return temperature and the primary flow temperature, the hybrid control module determines what proportion of the total energy to be expended should be covered by the condensing boiler and the external unit respectively. This process optimises the efficiency of the heating system.

The hybrid control module delivers the control signal at the interface to the air to water heat pump. This modulates the output of the external unit subject to the current heat demand.

A hydraulic separator is integrated into the hybrid manager and separates the condensing boiler and heating circuits. Thus, the heating water, after flowing through the hybrid manager, can be either routed through the condensing boiler or returned into the heating system.

A high efficiency (HE) pump integrated in the hybrid manager provides the heating water circulation through the hybrid manager. The hydraulic separator integrated into the hybrid manager also enables the HE pump operation in the hybrid manager when the pump inside the condensing boiler is not running.

The pump inside the condensing boiler and the HE pump in the hybrid manager run simultaneously if the condensing boiler operates on its own or at the same time as the air to water heat pump.

If only the air to water heat pump is in operation, then only the HE pump in the hybrid manager runs.

The filter protects the plate heat exchanger (condenser) inside the hybrid manager and the heating system from contamination through small particles with a diameter larger than 1 mm.

A flow switch with magnetic reed switch ensures that the external unit operates only if the water flow rate is adequate for the plate heat exchanger (condenser).

The heat exchange between the refrigerant (R410A) and the heating water takes place inside the copper-brazed stainless steel plate heat exchanger (condenser).

One temperature sensor each is located at the plate heat exchanger inlet and outlet to protect the heating water from excessively high temperatures during heating operation by the external unit and against freezing when the external unit is being defrosted. The heat transfer between the refrigerant(R410A) and the outside air takes place inside the heat exchanger of the external unit (evaporator).

The buffer tank provides two functions: Firstly, the buffer tank ensures that there is always sufficient heat energy within the heating system in order to support the Heat Pump Defrost operation. Secondly, the buffer volume prevents excessive heat pump cycling during low heat load conditions. This optimises system efficiency and reduces excessive wear on heat pump components.

### **BYPASS VALVE (OVERFLOW VALVE)**

This function is particularly important during automatic defrosting.

The bypass valve begins to open when the heat demand has been reached and the thermostatic valves reach their closed position. The heating water flows through the bypass valve and so safeguards the required minimum heating water flow rate through the hybrid manager.

## 2.9 HANDLING CIRCUIT BOARDS

Circuit boards with control electronics are sensitive to discharges of static electricity (ESD – ElectroStatic Discharge) when handled. To prevent damaging the components, special care is therefore required when handled.




Fig. 4 Earthed wristband

Damage is usually undetected, and a circuit board can operate normally during commissioning but may show signs of problems later.

A wristband connected to earth offers good ESD protection when working with electronics. Wear this wristband before opening any screened metallic packaging or exposing any fitted PCB's. Wear the wristband until the PCB has been placed inside its screened packaging or has been connected inside the closed external unit. Replaced PCBs that must be returned must also be treated this way.





Fig. 5 Handling electronic components

	<p><b>CAUTION:</b> Equipment damage through electrostatic discharge!</p> <p>▶ Never touch a PCB without an earthed wristband.</p>
--	---

2.10 REFRIGERANT CIRCUIT



6 720 646 970-04.3/ITL

Fig. 6 Refrigerant circuit

- [A] Refrigerant flow during defrosting
- [B] Refrigerant flow during heating
- [1] Heat exchanger / evaporator
- [2] Temperature sensor TH6 on the pipe to the evaporator
- [3] TH7 outside temperature sensor
- [4] Temperature sensor TH3 on pipe work for liquid refrigerant
- [5] Distributor
- [6] Temperature sensor TH33 on pipe work for liquid refrigerant
- [7] Dirt trap
- [8] Linear expansion valve LEV-A
- [9] Liquid receiver
- [10] Linear expansion valve LEV-B
- [11] Shut-off valve
- [12] Connection for liquid refrigerant
- [13] Connection for gaseous refrigerant
- [14] Shut-off valve with Schraeder valve
- [15] 4-way valve
- [16] Charging connection
- [17] High pressure switch 63H
- [18] Silencer
- [19] Temperature sensor TH4 for hot gas
- [20] Temperature sensor TH32 on compressor casing
- [21] Compressor

**2.11 COMBI BOILER WITH SERIAL BUFFER TANK, BYPASS VALVE AND UNMIXED HEATING CIRCUIT**




Fig. 7 System scheme with serial buffer tank, bypass valve and one unmixed heating circuit

- [1] Outside temperature sensor
- [2] Condensing boiler
- [3] Double pole fuse spur
- [4] FW200 programming unit
- [5] Radiator
- [6] Bypass valve for heating system with indicated flow direction
- [7] Expansion vessel
- [8] Serial buffer tank
- [9] Hybrid manager (internal unit) with hybrid control module
- [10] External unit

**2.12 SYSTEM BOILER WITH SERIAL BUFFER TANK, BYPASS VALVE AND UNMIXED HEATING CIRCUIT**




Fig. 8 System scheme with serial buffer tank, bypass valve and one unmixed heating circuit

- [1] Outside temperature sensor
- [2] Condensing boiler
- [3] Double pole fuse spur
- [4] FW200 programming unit
- [5] Radiator
- [6] Bypass valve for heating system with indicated flow direction
- [7] Serial buffer tank
- [8] Expansion vessel
- [9] Hybrid manager (internal unit) with hybrid control module
- [10] External unit
- [12] DHW cylinder

**2.13 COMBI BOILER WITH SERIAL BUFFER TANK, BYPASS VALVE, UNMIXED HEATING CIRCUIT AND INDEPENDENTLY CONTROLLED MIXED HEATING CIRCUIT**




Fig. 9 System scheme with serial buffer tank, bypass valve, one unmixed heating circuit and one mixed heating circuit

- [1] Outside temperature sensor
- [2] Condensing boiler
- [3] Double pole fuse spur
- [4] FW200 programming unit
- [5] Radiator
- [6] Bypass valve for heating system with indicated flow direction
- [7] Serial buffer tank
- [8] Expansion vessel
- [9] Hybrid manager (internal unit) with hybrid control module
- [10] External unit
- [11] Underfloor heating (independently controlled)

**2.14 SYSTEM BOILER WITH SERIAL BUFFER TANK, BYPASS VALVE, UNMIXED HEATING CIRCUIT AND INDEPENDENTLY CONTROLLED MIXED HEATING CIRCUIT**




Fig. 10 System scheme with serial buffer tank and one unmixed heating circuit

- [1] Outside temperature sensor
- [2] Condensing boiler
- [3] Double pole fuse spur
- [4] FW200 programming unit
- [5] Radiator
- [6] Bypass valve for heating system with indicated flow direction
- [7] Serial buffer tank
- [8] Expansion vessel
- [9] Hybrid manager (internal unit) with control module
- [10] External unit
- [11] Underfloor heating (independently controlled)
- [12] DHW cylinder

## 2.15 OVERVIEW OF COMPONENTS

### 2.15.1 GREENSTAR PLUS HYBRID MANAGER (INTERNAL UNIT)





Fig. 11 Main components of the hybrid manager

- [1] Connection, heating system return  
(22 mm compression fitting)
- [2] Connection, pipe to the heat source  
(22 mm compression fitting)
- [3] Isolation valves (water)
- [4] Hydraulic separator
- [5] Grundfos Alpha 2L HE pump, category A
- [6] Filter
- [7] Drain valve
- [8] Interface to the external unit
- [9] Hybrid control module
- [10] Heating water temperature sensor (at the condenser inlet)
- [11] Refrigerant temperature sensor (for liquid refrigerant)
- [12] Flow switch
- [13] Condenser  
(copper-brazed stainless steel plate heat exchanger)
- [14] Heating water temperature sensor (at the condenser outlet)
- [15] Pipework for gaseous refrigerant, Ø ½ "
- [16] Pipework for liquid refrigerant, Ø ¼ "
- [17] Connection, heating system flow  
(22 mm compression fitting)
- [18] Connection, pipe from the heat source  
(22 mm compression fitting)


**2.15.2 GREENSTAR PLUS HYBRID EXTERNAL UNIT**



6 720 646 970-49.3ITL

*Fig. 12 Main components and casing of external unit*

- [1] Air grille
- [2] Top casing panel
- [3] Front casing panel
- [4] Evaporator
- [5] Fan
- [6] 4-way valve
- [7] Cover for fill connection
- [8] Service cover
- [9] Connection for gaseous refrigerant with service connection
- [10] Connection for liquid refrigerant



6 720 646 970-58.61TL

Fig. 13 Main components of the external unit

- [1] Fan motor
- [2] Evaporator
- [3] Enclosure for electric components
- [4] Temperature sensor TH8
- [5] Power circuit board
- [6] Controller circuit board
- [7] Noise circuit board
- [8] Terminal strip
- [9] Temperature sensor TH7
- [10] Transformer
- [11] Temperature sensor TH6
- [12] Temperature sensor TH4
- [13] Temperature sensor TH32
- [14] Linear expansion valve LEV-B
- [15] High pressure switch
- [16] 4-way valve
- [17] Linear expansion valve LEV-A
- [18] Solenoid coil
- [19] Temperature sensor TH33
- [20] Temperature sensor TH3
- [21] Shut-off valve (pipe for liquid refrigerant)
- [22] Shut-off valve (pipe for gaseous refrigerant)
- [23] Service connection
- [24] Dirt trap
- [25] Refrigerant collector
- [26] Compressor
- [27] Silencer
- [28] Nut
- [29] Impeller

**2.16 DIMENSIONS**

**2.16.1 HYBRID MANAGER (INTERNAL UNIT)**




Fig. 14 Hybrid manager dimensions

**2.16.2 EXTERNAL UNIT**




Fig. 15 Dimensions of external unit

**2.17 TECHNICAL DATA**
**2.17.1 HYBRID SYSTEM**

Description	Unit	Value
Max. heating output <sup>1)</sup>	kW	25.14
Power supply	V/Hz/PH	230/50/1~
Refrigerant R410A	kg	2.5
Pipe for liquid refrigerant, external diameter	inch	¼
Pipe for gaseous refrigerant, external diameter	inch	½
Minimum water flow rate in the air to water heat pump circuit	l/min	6.0

*Table 2 Specification for hybrid system*

1) At 20 K ( $\Delta T$ ) between the heating system flow and return relative to a pressure drop of 200 mbar. For further information in the case of alternative pipe lengths and  $\Delta T$  see appendix in chapter 13.6, page 89.

**2.17.2 HYBRID MANAGER**

Description	Unit	Value
Max power consumption	W	50
Power supply, current rating	A	3
IP rating		IPX4D
Water content	l	1.4
Water flowrate range	l / min	6 to 20
Dimensions, internal unit (height x width x depth)	mm	500 x 390 x 360
Weight	kg	21

*Table 3 Specification for hybrid manager*
**2.17.3 EXTERNAL UNIT**

Description	Unit	Value
Power supply	V / Hz / ph	230 / 50 / 1~
Rated heating output (A2W35) <sup>1)</sup>	kW / COP	3.852 kW / 3.14
Max. heating output (A2W35) <sup>1)</sup>	kW / COP	4.613 kW / 2.78
Rated heating output (A7W35) <sup>1)</sup>	kW / COP	4.704 kW / 4.42
Max. heating output (A7W35) <sup>1)</sup>	kW / COP	6.084 kW / 4.11
Rated heating output (A-7W35) <sup>1)</sup>	kW / COP	2.985 kW / 2.31
Max. current	A	13
Recommended MCB/fuse rating	A	16 MCB type D
IP rating		IP24
Refrigerant - filling	kg	2.5
Air flow rate	m <sup>3</sup> /min	35
Sound level to EN 12102 <sup>2)</sup>	dB(A)	46
Dimensions (W x D x H)	mm	800 x 300 x 600
Control outside air temperature operating range	°C	-9 to +21
Storage temperature	°C	-25 to +60
Water flow temperature operating range	°C	+20 to +50
Weight	kg	42
Max. line length/height difference	m	30/30
Pipe work for liquid refrigerant external diameter	inch	¼
Pipe work for gaseous refrigerant external diameter	inch	½

*Table 4 Specification for external unit*

1) Reference conditions: to EN 14511-2:2007

2) Measured at a horizontal distance of 1 m and a height of 1.5 m taken from the appliance bottom

### 3 REGULATIONS

#### 3.1 STANDARDS, REGULATIONS AND GUIDELINES

The product is in compliance with the following EC directives:

- Low Voltage Directive 2006/95/ EC
- Electromagnetic Compatibility Directive 2004/108/EC.

##### 3.1.1 GENERAL REGULATIONS



Concerning the installation and operation of the hybrid system, observe the country-specific standards and directives.

Observe the details on the data plate of the components of the hybrid system.

Observe the following guidelines and regulations:

- Local regulations and requirements by the relevant power supply utility and the associated special connection requirements
- BS EN 378 Safety and environmental requirements for heat pumps
- BS EN 14511 Requirements heat pumps for space heating and cooling
- BS EN 14276-2:2007 Pressure equipment for refrigerating systems and heat pumps. Piping. General requirements
- BS EN 14324:2004 Brazing. Guidance on the application of brazed joints
- BS EN 12735-1:2010 Copper and copper alloys. Seamless, round copper tubes for air conditioning and refrigeration. Tubes for piping system
- European Parliament Regulation (EC) 842/2006 on Certain Fluorinated Greenhouse Gases
- Gas Safety Regulations 1998 (Installation and use)
- Building Regulations
- Building Regulations Northern Ireland)
- Building Regulations (Scotland) (Consolidation)
- IGE Gas Installation in Timber Frame Buildings
- Law no. 46 of 5/3/1990 - Regulations for the safety of installation
- Standard UNI-CIG 7129 - gas installations for domestic use supplied from the mains network
- Standard UNI 11071 - Gas installation for domestic use controlled be condensing and similar appliances
- Any other local requirement
  - The Health and Safety at Work Act 1974
  - The Management of Health and Safety at Work Regulations 1999
  - The Construction (Health, Safety and Welfare) Regulations 1996
  - The Construction (Design and Management) Regulations 1994
  - The Lifting Operations and Lifting Equipment Regulations 1998

Where no specific instruction is given, reference should be made to the relevant codes of Practice.

Potable water: All seals, joints, compounds (including flux and solder) and components used as part of the secondary domestic water system must be approved for use with potable water supplies.

This is to certify that the above ranges of products manufactured by Bosch Thermotechnology have been tested and found to comply with:

- The requirements of the (Water Fittings) Regulations 1999 for England and Wales, the Water Byelaws 2000, Scotland and the Water Regulations Northern Ireland.
- The requirements of the UK Building Regulations:
  - The Building Regulations 1991 (England & Wales) Requirements G3, L1 and Regulation 7.
  - The Building Standards (Scotland) Regulations 1990. Regulation 10 (B2), 22 (J3.3a and J3.4), 27 and 28 (P2.6 and P3).

- The Building Regulations (Northern Ireland) 2000.

The relevant Standards to be followed include:

- BS 1306 Specification for copper and copper alloy pressure piping systems
- BS 5440:1 Flues and ventilation for gas appliances of rated heating not exceeding 70kW (net): Flues
- BS 5440:2 Flues and ventilation for gas appliances of rated heating not exceeding 70kW (net): Air Supply
- BS 6798 Installation of gas fired boilers of rated input up to 70kW (net)
- BS 7074:1 Code of practice for domestic and hot water supply
- BS 6891 Installation of low pressure gas pipe work up to 28 mm (R1)
- BS 5546 Installation of gas hot water supplies for domestic purposes
- EN:12828 Central heating for domestic premises 3 Product Description
- BS 7593 Treatment of water in domestic hot water central heating system

### 4 TRANSPORT



**WARNING:** Risk of injury through improper handling.

- ▶ Use a means of transport suitable for handling appliances (e.g. sack truck with strap, stair climbing or step trolley).
- ▶ When handling appliances, secure them against a fall.
- ▶ Let only trained personnel undertake the handling.

During handling, also observe the following:

- ▶ Never lift packages by the shipping straps.
- ▶ Wear safety gloves as sharp edges can result in cuts.

#### 4.1 LIFTING AND CARRYING THE EXTERNAL UNIT



**WARNING:** Risk of injury through incorrect lifting and carrying!

The external unit weighs in excess of 20 kg.

- ▶ Never lift or carry the external unit on your own.

Handling by trained personnel:

- ▶ Only remove packaging at the time of the final installation.
- ▶ At least two people should lift and carry the external unit.
- ▶ Only move the external unit upright.
- ▶ Never carry the external unit by the packing straps.
- ▶ During handling and unpacking, wear safety gloves to prevent injuries on your hands through sharp-edged appliance components.
- ▶ Dispose of packaging materials appropriately.

#### 4.2 UNPACKING THE EXTERNAL UNIT



**WARNING:** Risk of injury through sharp-edged tools.

- ▶ Handle tools carefully.
- ▶ Ensure that the outer carton is not damaged when removing the straps.

- ▶ Undo straps carefully.
- ▶ Remove the outer carton by pulling it vertically upwards.
- ▶ Remove the padding from the front and sides.
- ▶ Remove the plastic cover and protective cover from the top of the external unit and keep safe.
- ▶ Provide at least two people for lifting the external unit from the bottom plate.
- ▶ Ensure that this does not damage the external unit.
- ▶ Dispose of packaging in an environmentally responsible manner.

### 4.3 UNPACKING THE HYBRID MANAGER



**NOTICE:** Damage to the hybrid manager and refrigerant pipes may occur through incorrect handling.

- ▶ Treat refrigerant pipes and the hybrid manager with care.

- ▶ Upon receipt, check that all packaging is in perfect condition.
- ▶ Remove packing straps and open the packaging at the top.
- ▶ Remove mounting plate and printed documents; keep safe for later use.
- ▶ Remove outer packaging.
- ▶ Remove protective packaging.
- ▶ Dispose of packaging in an environmentally responsible manner.
- ▶ Carefully place the appliance on its back.
- ▶ Undo screws at the top and bottom of the appliance.
- ▶ Remove casing.
- ▶ Remove the screws on the transport bracket.
- ▶ Remove the transport bracket.
- ▶ Refit casing and screws.

### 4.4 CHECKING THE DELIVERY

- ▶ Check the delivery for completeness.

## 5 MOUNTING AND INSTALLATION

### 5.1 PREPARING FOR INSTALLATION



**DANGER:** Danger to life through electric shock!

- ▶ Before carrying out work on electrical components, isolate them from the power supply (230 V AC) (fuse, circuit breaker) and secure against unintentional reconnection.



**WARNING:** Risk of injury and damage to appliance through incorrect mounting and installation.

- ▶ The hybrid system and the components may only be sited and installed by a competent person.



**For commissioning:**

The Power supply to the external unit must be "On" for at least 12 hours before starting operation. This is to ensure that the compressor is warmed up sufficiently to avoid any liquid refrigerant from entering the compressor. This is particularly important during colder periods. The 12 hour period also compensates for any unsettling of the lubricating oil within the compressor which may have occurred during transportation. If this 12 hour time period cannot be met damage to the outdoor unit may result. Therefore, make the electrical connection as early as needed (→ chapter 5.7).

#### 5.1.1 CLEANING PRIMARY SYSTEMS



**CAUTION:**

ISOLATE THE MAINS SUPPLIES BEFORE STARTING ANY WORK AND OBSERVE ALL RELEVANT SAFETY PRECAUTIONS.



Worcester Bosch recommends the fitting of an in-line system filter to the primary circuit which will assist with maintaining system performance.



**NOTICE:**

Debris from the system can damage the hybrid manager and reduce efficiency.

Failure to comply with the guidelines for the use of water treatment with the appliance will invalidate the appliance warranty.

#### BEFORE CLEANING THE SYSTEM:



**NOTICE:** Damage through high water flow:

The flow switch is damaged if the water flow is excessively high.

- ▶ Flush the heating system with a water flow of  $\leq 50$  l/min.

- ▶ Ensure that the system and pipe work is in good working order.
- ▶ **Where possible keep the existing boiler/circulating pump in place when flushing the system.**

#### FOLLOW THE GUIDANCE OF BS7593:

Treatment of water in domestic hot water central heating and also the flushing guidelines below.



**NOTICE:** ARTIFICIALLY SOFTENED WATER MUST NOT BE USED TO FILL THE CENTRAL HEATING SYSTEM.

#### FLUSHING THE SYSTEM

- ▶ Fill the system with cold water and check for leaks.
- ▶ Open all drain cocks and drain the system.
- ▶ Close drain cocks and add a suitable flushing agent **compatible with aluminium** at the correct strength for the system conditions in accordance with the manufacturer's instructions.  
**The pH value of the system water must be less than 8 or the appliance guarantee will be invalidated.**
- ▶ Circulate the flushing agent before the boiler is fired up.
- ▶ Run the boiler/system at normal operating temperature as directed by the manufacturer of the flushing agent.
- ▶ Drain and thoroughly flush the system to remove the flushing agent and debris.
- ▶ It may be necessary to use a power flushing machine to aid the cleansing procedure in some circumstances.
- ▶ Close the drain cocks and refill with fresh water and a suitable inhibitor.
- ▶ Vent any air from the boiler and system.

#### INHIBITOR

Add a suitable inhibitor or combined inhibitor/anti-freeze, if the system is exposed to freezing conditions, to the heating system in accordance with the DWTA code of practice and manufacturer's guidelines.



**WARNING:** Sealing agents

- ▶ Normally the addition of sealing agents to the system water is not permitted as this can cause problems with deposits left in the heat exchanger.
- ▶ In cases where all attempts to find a micro leak have failed, Worcester, Bosch Group supports the use of Fernox F4 leak sealer.

## WATER TREATMENT PRODUCTS

Suitable water treatment products can be obtained from the following manufacturers:

FERNOX	0870 601 5000 or www.fernox.com
SENTNEL	0800 389 4670 or www.sentinel-solutions.net

Table 5

## ARTIFICIALLY SOFTENED WATER

It is possible to have an ion exchange water softener fitted to the cold water system of the property. However, the boiler requires an untreated cold water connection taken from the mains supply, before the water softener, to the primary water filling point of the heating system.

Alternatively there are water softening/treatment devices that do not adjust or alter the pH levels of the water. With these devices it may not be necessary to provide an untreated water by-pass to the primary water filling point of the heat system.

## 5.2 SYSTEM COMPONENT CONFIGURATION

### 5.2.1 GENERAL REQUIREMENTS



The following requirements must be met. The following sections detail additional requirements for the installation of the individual system components.



It is important the pump speed is set correctly, please set the HE pump inside the hybrid manager (→ chapter 6.2.9, page 35).

- The permissible maximum length of the refrigerant lines between the external unit and the hybrid manager is 30 m with up to 15 bends (single direction).
- The permissible minimum length of the refrigerant lines between the external unit and the hybrid manager is 1 m in a single direction.
- A height differential between the installation site and the hybrid manager is permissible. However, take the maximum pipe length of 30 m into account.
- If the hybrid manager is mounted above the heat source, fit an automatic air vent valve at the highest point of the heating system.
- The maximum equivalent length of pipe work with which the hybrid manager is connected to the existing heating system flow and return should be determined from tables 50 and 51. One metre must be subtracted for each 90° bend.
- Rooms where the hybrid manager or the refrigerant lines are installed must have a volume of at least 5.7 m<sup>3</sup>, if the room can be occupied.

### 5.2.2 BUFFER TANK



#### NOTICE:

- ▶ Please refer to the Buffer tank installation instructions for correct hydraulic connection.

The buffer tank must be installed in series in the flow between the hybrid manager and the system by-pass.

### 5.2.3 BYPASS VALVE

The bypass valve is connected between the flow out from the buffer vessel and the first radiator on the heating system.

Further requirements of the installation site:

- The bypass valve must be fitted into a straight pipe section and not immediately near a bend.
- For commissioning and maintenance the bypass valve must be easily accessible.

- Fit the bypass valve as near as possible to the heating system and as far away as possible from the buffer vessel.

### 5.2.4 EXPANSION VESSEL

Install an additional expansion vessel on the heating system return between the bypass valve and the hybrid manager. Size the expansion vessel according to EN128-28.

### 5.2.5 THERMOSTATIC RADIATOR VALVES

For optimum comfort and system efficiency a thermostatic radiator valve should be fitted to each radiator within the circuit, except for the radiator in the same room as the room controller.

### 5.2.6 HYBRID MANAGER



**WARNING:** Rooms where the hybrid manager or the refrigerant lines are installed must have an internal volume of at least 5.7 m<sup>3</sup>, if the room can be occupied.

Information on the installation site:

- Ensure minimum clearances are maintained.
- Mount the hybrid manager on to a fixed rigid wall capable of supporting the weight of the unit.
- To reduce the installation effort we recommend the installation of the hybrid manager below the heat source (→ Fig. 7, page 9).
- Flow and return pipes can be routed vertically from the top or bottom into the hybrid manager.
- Refrigerant lines can be routed vertically from the top into the hybrid manager.
- If refrigerant lines are to be routed downwards, allow for adequate space to route the pipes downwards alongside the unit, preferably on the left hand side.

### MINIMUM CLEARANCES



Dimensions given are minimum clearances around the Hybrid manager for the purposes of installation and service.

The minimum volumetric requirements of the room size must also be adhered to according to EN: 14511.




Fig. 16 Minimum clearances, hybrid manager

- [a] Top clearance: 250 mm
- [b] Bottom clearance: 200 mm
- [c] Front clearance: 800 mm for maintenance
- [d] Side clearance: 5 mm

### 5.2.7 EXTERNAL UNIT



#### DANGER:

- ▶ Never site the external unit in locations where flammable gases could be released, accumulate or flow past.

**AMBIENT CONDITIONS AND SITE LOCATION.**

The ambient conditions and site location significantly influence the external unit's output and service life. Unfavourable ambient conditions or site location can result in a significant reduction in output and even possible appliance damage.

- Never site the external unit where it is exposed to vapour, volatile oils (incl. machine oil) or sulphurous gas.
- In areas with a high salt content (e.g. on the coast), advice should be taken on the protection of the unit's evaporator.
- If snow is expected, take appropriate measures to ensure that the external unit cannot be covered by snow.
- In cold or frosty areas ensure that the condensate can drain off freely (e.g. by means of a condensate drain or pan).
- Preferably avoid installing the external unit in locations where it would be exposed to direct or to other heat sources.

**FOUNDATION**

- The installation surface must be level, firm and of appropriate load-bearing capacity. It must be able to bear the weight and absorb the vibrations of the external unit.
- Wooden bases are unsuitable installation areas.
- Requirements for concrete foundations:
  - Thickness of concrete:  $\geq 120\text{mm}$
  - Load-bearing capacity:  $\geq 320\text{ kg}$
- Length of fixing screws:  $\geq 70\text{ mm}$  (subject to foundation).

**INSTALLATION SITE IN GENERAL**

- Select an installation site (floor standing or wall mounting (available as an accessory) installation) where the external unit creates no noise nuisance for other occupants or the neighbourhood.
- Select an installation site where wiring and pipe work to power source and hybrid manager can be easily accomplished.
- The external unit produces condensation during the heating operation. Ensure suitable drainage is provided around the external unit if such condensation is likely to cause risk of injury or damage.
- It is important that flue products or condensate do not drip onto or enter the air intake of the external unit. Therefore, never locate the external unit in immediate proximity or directly below the boiler flue outlet.
- Recirculation of the discharge air can severely affect the output.
- We recommend a floor standing installation where possible.

**WINDY LOCATION**

If the external unit is sited on a roof or another site exposed to the wind, ensure that the air discharge is not directly exposed to strong wind.

Possible preventive measures to safeguard against strong wind:

- ▶ Direct the air discharge towards the nearest wall. The minimum clearance must be 1000mm.




Fig. 17 Orientation towards a wall (windy location)

[a] Minimum wall clearance 1000mm



If the air discharge is oriented directly against a wall this may discolour over time.

- ▶ Direct the air discharge at an angle of 90° to the main wind direction [1].




Fig. 18 Air discharge alignment

[1] Main wind direction

**MINIMUM CLEARANCES**




Fig. 19 Minimum clearances for specific installation situations

Pos.	Obstacle	Clearance [mm]	Pos.	Obstacle	Clearance [mm]
1	• Rear	• $a \geq 150$	4	• Front	• $c \geq 1000$
2	• Rear • Above	• $a1 \geq 300$ • $e \geq 1000$ • $f \leq 500$	5	• Front • Rear	• $a \geq 150$ • $c \geq 1000$
3	• Rear • Sides • Connection side	• $a1 \geq 300$ • $b \geq 200$ • $d \geq 200$	6	• Rear • Sides • Above • Connection side	• $a2 \geq 500$ • $b \geq 200$ • $d1 \geq 250$ • $e \geq 1500$ • $f \leq 500$

Table 6 Key to Fig. 19

## MOUNTING AND INSTALLATION

### 5.3 PRE-INSTALLING PIPES



Contamination in the system can result in damage to the air to water heat pump and reduce the output.

#### 5.3.1 PREPARING THE HYBRID MANAGER CONNECTION

- ▶ Installing on-site pipe work. For this, observe the information on system component configuration (→ chapter 5.2).



Pipe work may be routed vertically or behind the appliance.

- ▶ Drill six holes into the wall using the drilling template provided [1].
- ▶ Insert suitable wall plugs.
- ▶ Fit the mounting plate of the hybrid manager to the wall using the top drilled holes [2].




Fig. 20 Fitting the mounting plate

- ▶ Connect the heat source pipe work and that of the heating system to the mounting plate. Ensure your connections are correct (→ Fig. 21).
  - Fit the pipe fully into the pipe connection.
  - Tighten the compression fitting.




Fig. 21 Hybrid manager mounting plate

- [1] Mounting plate
- [2] Heating system return (22 mm compression fitting)
- [3] Pipe work to the heat source (22 mm compression fitting)
- [4] Pipe work from the heat source (22 mm compression fitting)
- [5] Heating system flow (22 mm compression fitting)



**NOTICE:** Buffer tank installation:

- ▶ refer to the instructions provided with the buffer tank.

### 5.3.2 FITTING THE BYPASS VALVE



Regarding the arrangement and position of the bypass valve, observe the information in section 5.2.3.

- ▶ Connect the bypass valve between the heating system flow and return.
- ▶ Install the bypass valve in the flow direction from the flow to the return. The flow direction is identified on the bypass valve by an arrow.




Fig. 22 Mounting the bypass valve in flow direction

- [1] From the heating system flow
- [2] To the heating system return

### 5.3.3 MOUNTING THE FW200 PROGRAMMING UNIT



The FW200 must never be fitted in the front of the gas appliance, and must not be placed in direct sun light. The programming unit is mounted on the wall and it is electrically linked via the hybrid control module via CANBUS cable.

All installation information for the FW200 can be found in the separate FW200 installation manual.

## 5.4 MOUNTING THE HYBRID MANAGER

### PREREQUISITES

Prior to starting the mounting of the hybrid manager, ensure that the on-site conditions have been met (→ chapter 5.2, from page 21).

- Where the unit is being fitted to an existing heating system ensure the system has been flushed and cleaned prior to fitting of the Hybrid manager unit (→ chapter 5.1.1).
- The required minimum clearances are ensured (→ chapter 5.2.6).
- The mounting plate has been secured to the wall and is correctly connected (→ chapter 5.3.1).
- The bypass valve has been fitted correctly (→ chapter 5.3.2).

**CASING REMOVAL**

1. Undo the outer case screws [1].
2. Lift off the case.




Fig. 23 Casing removal

[1] Fixing screws

**WALL MOUNTING**

- ▶ Undo the fixing screws of the casing at the top and bottom of the hybrid manager.
- ▶ Remove the casing.
- ▶ Undo fixing screw on the left [1] of the hybrid control module.
- ▶ Push out the spring plate [2] and tilt the hybrid control module forward.




Fig. 24 Tilting the hybrid control module forward

[1] Fixing screw  
[2] Spring plate

- ▶ Remove the front and side insulation panels of the hybrid manager and keep safely for later reassembly.




Fig. 25 Remove insulation from the hybrid manager

- ▶ Reposition the hybrid control module.




Fig. 26 Reposition the hybrid control module

1. Screw both top screws for the hybrid manager almost all the way into the wall, but do not tighten them fully.

- ▶ Raise the hybrid manager and hook it onto both screws.

2. Connect pipe work. For this, on every connection:

- Insert fibre gasket
- Tighten the union nuts of all connections.

- ▶ Tighten both top fixing screws of the hybrid manager wall mounting plate.

3. Fit and tighten the lower fixing screws on the wall mounting plate.

- ▶ Lower the control module.

- ▶ Insert the side and front insulation piece.

- ▶ Reposition the hybrid control module until the spring plate clicks into place.

- ▶ Push casing onto appliance

4. Tighten the fixing screws of the casing at the top and bottom of the hybrid manager.




Fig. 27 Mounting the hybrid manager on the wall

**5.5 INSTALLING THE EXTERNAL UNIT**

**PREREQUISITES**

Prior to siting and installing of the external unit, ensure that the on-site conditions have been met (→ chapter 5.2, from page 21).

- Required on-site steps have been taken correctly and have been completed.
- The required minimum clearances are ensured (→ chapter 5.2.7).
- The condensate drain has been prepared (→ chapter 5.5.1).

## MOUNTING AND INSTALLATION

### 5.5.1 PREPARING THE CONDENSATE DRAIN FOR THE EXTERNAL UNIT

**NOTICE:** Damage from moisture!  
Spilled condensate can be a nuisance as well as a hazard if it leaks onto a walkway and freezes.

- ▶ Never permit condensate to drain across walkways; instead, route them to a suitable drainage point.

In addition to the condensate lines for the heat source, make provisions for the condensate generated in the external unit.

Unlike boiler condensate, the condensate produced by the external unit is not acidic and can soak away in chippings or be routed to a drain. The diameter, slope and routing of the condensate pipe work must be selected in such a way as to prevent blockage or freezing.

Preparing the condensate drain:

- ▶ Use a PVC rigid vinyl pipe (VP-32) or a vinyl hose with a minimum internal diameter of 32 mm as condensate drain.
- ▶ Select the shortest possible pipe length.
- ▶ Keep condensate lines as vertical as possible with a minimum slope of 45 mm per metre to its outlet.

**i** We recommend providing the pipe work with weather-resistant insulation.

### 5.5.2 MOUNTING ON FOUNDATIONS

**WARNING:** Personal injury from unsuitable surfaces!  
An external unit that has not been properly sited may fall over and cause personal injury and property damage.

- ▶ Site the external unit on a stable, level substrate with sufficient load-bearing capacity.
- ▶ Never site the external unit on wooden floors.

- ▶ Ensure that the foundations and installation surface meets requirements (→ chapter 5.2.7).
- ▶ Position and level the external unit.
- ▶ Mark out the holes to be drilled for the 4 anchor bolts.
- ▶ Move the external unit slightly to the side.
- ▶ Drill the holes for the 4 anchor bolts.
  - Bolt size: M 10
  - Select a hole depth that allows the anchor bolts to be screwed into the foundations to a depth of at least 70 mm.
- ▶ Level the external unit.
- ▶ Secure the feet of the external unit with four M 10 anchor bolts.




Fig. 28 Foundations for the external unit (2 plinth example shown)

- [a] As long as possible, minimum 365 mm
- [b] Minimum depth 120 mm
- [1] M 10 anchor bolt ( $\geq 70$  mm)

### 5.5.3 MAKING A CONDENSATE DRAIN FOR THE EXTERNAL UNIT

**NOTICE:** Frost damage!  
Frost damage on the external unit will result if the condensate fails to drain off.

- ▶ Either install a condensate drain or an optional condensate pan fitted with a drain for the external unit.

The condensate generated in the external unit must be drained off free from the risk of frost.

- ▶ Ensure that the on-site requirements for reliable condensate drainage are met (→ chapter 5.5.1).

The bottom of the external unit has 3 holes suitable for draining off condensate.




Fig. 29 Fitting the condensate drain

- [1] Condensate pipe
- [2] Drain tap
- [3] Blanking caps (accessory)

- ▶ Glue the drain tap [2] into a suitable hole.
- ▶ Glue blanking caps [3] onto the other holes that are not used. Apply adhesive properly as it also acts as a sealant.
- ▶ Connect the condensate hose [1] to the drain tap.
- ▶ Apply weather-resistant insulation to the drain pipe.
- ▶ Route the condensate drain into a suitable drain pipe or a dry well.
- ▶ Protect against the risk of frost:  
We recommend the use of the “electric trace heating for the condensate drain of the external unit” (available as an accessory).

Accessory pack for outdoor unit contains:

- Blanking caps
- Pre-cut insulation (for lagging the service/installer connections)
- Cable ties (for securing lagging of service/installer connections)

## 5.6 INSTALLING THE REFRIGERANT CIRCUIT

### 5.6.1 SAFETY

R410A is used exclusively as the refrigerant in the air to water heat pump.



Compared to previously used refrigerants, the R410A refrigerant operates at a pressure that is approx. 1.6-times higher.

- ▶ Only qualified and authorised refrigeration engineers may work on the refrigerant system.
- ▶ For the installation work, use tools and pipe components specifically made for use with R410A refrigerant.
- ▶ Check for leaks in the refrigerant system. Escaping refrigerant coming into contact with a naked flame will produce poisonous gases.
- ▶ Never release refrigerant to the atmosphere.

If refrigerant leaks and touches the skin, it can cause frostbite.

- ▶ In case of a refrigerant leak, never touch any part of the air to water heat pump.
- ▶ Avoid skin or eye contact with refrigerant.
- ▶ Seek medical attention if you get refrigerant on your skin or in your eyes.

### 5.6.2 PREPARING FOR INSTALLATION



**CAUTION:** Property damage from incorrect installation!

- ▶ Use only those tools that are specifically intended for handling R410A refrigerant.

Tools required to handle R410A refrigerant:

- Pressure gauge kit
- Charge hose
- Gas leak detector
- Torque wrench
- Flaring tool
- Flaring gauge
- Vacuum pump adapter
- Electronic refrigerant charging scale
- Pipe press tool

### PIPES AND PIPE JOINTS



**WARNING:** Risk of injury through escaping refrigerant! Pipes that are not permissible or that are incorrectly sized can burst.

- ▶ Use exclusively pipes with the specified wall thickness.

Pipe	External diameter [inch]	Wall thickness [mm]
Liquid refrigerant	¼	0.8
Gaseous refrigerant	½	0.8

Table 7 Refrigerant pipe dimensions

- ▶ Ensure the insides of the pipes are clean and do not contain any harmful contaminants such as sulphuric compounds, oxidants, debris, or dust.
  - Never store the refrigerant pipes to be used outdoors.
  - Do not unseal the pipe ends until immediately before they are brazed.

- Apply the utmost care when routing refrigerant lines. Dust, foreign bodies and moisture inside the refrigerant lines can be detrimental to oil quality or result in compressor failure.
- ▶ Use C1220 phosphorous copper for refrigerant pipe connections to create seamless pipes from copper and copper alloys.
- ▶ Braze joints in refrigerant lines. Use phosphor bronze brazing rods suitable for flux-free brazing.



Ensure that the lines are constantly shielded with oxygen-free nitrogen (a little above atmospheric pressure) whilst joints are being brazed to prevent scaling and damage to the compressor.

- ▶ Apply small amounts of ester oil, ether oil or alkylbenzene as refrigerant oil onto the flared sections of the refrigerant lines. Never mix refrigerant oil with mineral oil.
- ▶ After cutting, immediately seal reusable lengths of refrigerant lines.

### 5.6.3 ROUTING REFRIGERANT LINES



The room volume must be at least 5.7 m<sup>3</sup> if refrigerant lines are routed through occupied rooms.

- ▶ Ensure requirements have been met:
  - A height differential between the installation site and the hybrid manager is permissible. However, take the maximum pipe length of 30 m into account.
  - The refrigerant line may have a maximum of 15 bends and a maximum length of 30 metres one way.
- ▶ Start by connecting the refrigerant lines to the hybrid manager (mounting plate).
- ▶ Bend pipes carefully to prevent breaking them. Bending radii between 100 mm and 150 mm are adequate.



When brazing joints, ensure that the lines are constantly shielded with oxygen-free nitrogen (a little above atmospheric pressure). After brazing has been completed, continue shielding the brazed area with nitrogen until the temperature of the pipe work has cooled down to below 200 °C.

- ▶ Generally braze refrigerant line joints.
- ▶ Wrap pipe work for liquid and gaseous refrigerant with commercially available insulation (diffusion-proof, up to at least 100 °C, thickness at least 20 mm).
- ▶ Use sealant to seal the ends of the thermal insulation around the pipe connection sections to prevent water from entering the thermal insulation.

### 5.6.4 CONNECTING THE HYBRID MANAGER



When brazing joints, ensure that the lines are constantly shielded with oxygen-free nitrogen (a little above atmospheric pressure). After brazing has been completed, continue shielding the brazed area with nitrogen until the temperature of the pipe work has cooled down to below 200 °C.

- ▶ Remove plug and braze the ¼ " diameter to the pipe work for liquid refrigerant and the ½ " diameter to the pipe work for gaseous refrigerant at the hybrid manager.

**5.6.5 CONNECTING THE EXTERNAL UNIT**

Never connect the refrigerant lines to the external unit until

- the refrigerant lines have been completely arranged
- the refrigerant lines have been connected to the hybrid manager.



At the factory, the external unit has been filled with sufficient R410A refrigerant for a line length (single direction) of between 1 m and 30 m.

- ▶ Connect the external unit to the refrigerant line after completing the installation work, including the connection to the hybrid manager (internal unit).
- ▶ Remove the service cover (1 screw).
- ▶ Close the external unit's shut-off valve completely.
- ▶ Fit the flare nut (17 mm external diameter) to the liquid refrigerant pipe.
- ▶ Fit the flare nut (26 mm external diameter) to the gaseous refrigerant pipe.
- ▶ Flare the pipes for liquid and gaseous refrigerant (→ Fig. 30 and table 8).




Fig. 30 Flaring refrigerant pipes

Pipe	External diameter [inch]	Flaring dimension Ø A [mm]
Liquid refrigerant	¼	8.9 – 9.1
Gaseous refrigerant	½	16.2 – 16.6

Table 8 Swaging dimensions for refrigerant pipes

- ▶ Apply a thin layer of refrigeration oil to pipe and joint seating surface before tightening flare nut.




Fig. 31 Fitting refrigerant pipes

- [1] Connection to the external unit
- [2] Flared refrigerant pipe
- [3] Conical nut

- ▶ Tighten conical nut [3] with a torque wrench. Observe the allowable starting torque when doing so (→ Table 9).

Pipe work	External diameter [inch]	OD conical nut [mm]	Torque [Nm]
Liquid refrigerant	¼	17	14 – 18
Gaseous refrigerant	½	26	49 – 61

Table 9 Starting torque, external unit

- ▶ There should be no contact with the outer case of the ODU.
- ▶ There should be no contact between the liquid and gas refrigerant pipes.

**5.6.6 CHECKING THE REFRIGERANT CIRCUIT FOR TIGHTNESS**



The addition "(g)" identifies the stated value as pressure differential relative to atmospheric pressure.

After connecting the refrigerant pipes, check the connected pipes and the hybrid manager for tightness.

- ▶ Connect the testing tools.
- ▶ Ensure that the shut-off valves on the pipe work for liquid [1] (→ Fig. 32 and page 29). and gaseous refrigerant [2] (→ Fig. 32 and page 29) are closed and do not open them.
- ▶ Feed nitrogen into the refrigerant lines via the shut-off valve's Schrader valve on the gaseous refrigerant pipe work [2] and slowly increase the pressure in the refrigerant circuit.
- ▶ Increase the pressure in stages:
  - Step 1: build pressure to 0.5 MPa (5 bar(g)).  
Wait 5 minutes.  
Check pressure. A pressure drop indicates that there is a leak. Identify the source, repair and check for tightness again.
  - Step 2: build pressure to 1.5 MPa (15 bar(g)).  
Wait 5 minutes.  
Check pressure. A pressure drop indicates that there is a leak. Identify the source, repair and check for tightness again.
  - Step 3: Pressurise to 4.15 MPa (41.5 bar(g)).  
Measure the ambient temperature and the pressure.
- ▶ After 24 hours, check ambient temperature and pressure again. The refrigerant circuit has passed the tightness test if no pressure drop can be identified.



A minor change in pressure can be caused by the change in temperature (approx. 0.01 MPa (0.1 bar(g)) per 1 °C). Take this into account in the evaluation.

- ▶ A pressure drop indicates that there is a leak. Identify the source, repair and check for tightness again. Use a gas leak detector or a soapy solution to check for gas leaks.




Fig. 32 Shut-off valves, refrigerant circuit

- [1] Shut-off valve on the liquid refrigerant pipe work
- [2] Shut-off valve on the gas pipe work
- [3] Schrader valve (under the service port)
- [4] Section opening / closing
- [5] Service port
- [6] **Do not use a spanner here**
- [7] **Use two spanners here**
- [8] Insulation
- [9] ¼ inch pipe
- [10] ½ inch pipe

### 5.6.7 INSULATING THE REFRIGERANT SHUT-OFF VALVE

Insulate the refrigerant pipes, including the shut-off valve, following connection to the external unit.

- ▶ Trim insulation material [3] so that it fits snug around the refrigerant valves.
- ▶ Install the insulation [3] for the liquid refrigerant pipes (small, 2 holes) on the liquid side so that the holes fit the valve caps [1] and cover the shut-off valve [2] entirely.
- ▶ Trim the insulating material for the liquid refrigerant pipe work and make 2 holes for the locking caps.
- ▶ Fix to the pipe so that the holes surround the locking caps [1] and the shut-off valve [2] is completely covered.




Fig. 33 Insulating material, shut-off valve and valve caps

- [1] Locking caps
  - [2] Lock nut
  - [3] Insulating material (accessory drain kit EHP)
- ▶ Secure insulating material [1] with cable ties.

- ▶ Trim off the excess “tails” of the cable ties [2].




Fig. 34 Insulation with cable ties

- [1] Insulating material (accessory drain kit EHP)
- [2] Cable tie (accessory drain kit EHP)

- ▶ Trim and fix the insulating material [1] for the gaseous refrigerant pipe work.
- ▶ Fix the insulation material [1] using cable ties [2].
- ▶ Trim off the excess “tails” of the cable ties [2].

### 5.6.8 EVACUATING AND DRYING THE REFRIGERANT CIRCUIT

**WARNING:** Personal injury from rupturing refrigerant pipes!  
Air bubbles trapped in lines can result in pressure peaks which can result in pipes bursting.

- ▶ Never allow air to remain in the lines.

**i** The refrigerant circuit is pre-charged with 2.5 kg of R410A refrigerant. Commissioning does not require topping up with refrigerant.

Remove air from the refrigerant circuit by following recommended procedure for vacuum drying. In the case of inadequate vacuum drying air and water vapours remain in the refrigerant circuit. These may result in an abnormal rise in positive pressure or in a drop in negative pressure as well as to a loss of quality in the refrigerant oil through moisture. This may have a negative effect on the compressor service life.

### VACUUM DRYING

**i** Never use the refrigerant from the external unit to purge air from the refrigerant lines.

- ▶ Connect a high performance vacuum pump to the Schrader valve (→ Fig. 32, [3]).
- ▶ With the vacuum pump build a pressure of 101 kPa(g) (5 Torr).
- ▶ Maintain this pressure **for at least 1 hour**.
  - During this time check the vacuum pressure constantly at the pressure gauge.
  - If there is any moisture left in the pipe, complete evacuation is sometimes not reached if the vacuum pump is applied for only a short period.
- ▶ Close the distributor valve and then switch off the vacuum pump.
- ▶ Observe the pressure for one minute. Should the pressure rise during that time (vacuum reduces), evacuate and repeat the final test.
- ▶ Separate the vacuum pump from the refrigerant circuit.

**OPENING THE SHUT-OFF VALVES**

 **NOTICE:** Material loss from closed shut-off valves. Compressor and control valves will suffer damage if the shut-off valves remain shut during the operation of the external unit.

- ▶ Open shut-off valves for liquid and gaseous refrigerant.

Opening the shut-off valves on the liquid and gaseous refrigerant pipe work (→ Fig. 35):

- ▶ Remove valve cap [2].
- ▶ With an Allen key (4 mm) turn the valve spindle [3] anti-clockwise as far as it will go (approx. 10 turns). Stop turning once the end-stop has been reached.
- ▶ Turn valve rod [3] ½ one turn back (clockwise).
- ▶ Attach valve cap [2]. When doing this ensure that the inside remains undamaged as this serves as a sealing face.
- ▶ Tighten valve cap [2] with a torque of between 20 and 25 Nm. Failure to replace and tighten the caps may result in refrigerant leakage.




Fig. 35 Shut-off valve on the gaseous refrigerant pipe work

- [1] Schrader valve (under service cap)
- [2] Isolation valve cap
- [3] Isolation valve spindle
- [4] Pipe work to building
- [5] Pipe work to the external unit

**5.7 MAKING THE ELECTRICAL CONNECTION**

**5.7.1 SAFETY**

 **DANGER:** Risk to life through electric shock! Incorrectly executed work on electrical components can result in life-threatening electric shocks.

- ▶ Only qualified electricians must carry out work on electrical components. If you do not possess an appropriate qualification, ask a qualified electrician to make the electrical connection.

 **WARNING:** Do not connect the trace heating cable to the electrical connection of the outdoor unit. If this is done severe damage to the outdoor unit will result.

- ▶ Prior to making the electrical connection, isolate the heat source and all other BUS subscribers from the power supply.
- ▶ Before opening the external unit or the hybrid manager: Isolate all MCBs from the mains supply and secure against unintentional reconnection. Switching off the programming unit is not enough.
- ▶ Only use cables and leads for connecting the external unit to the power supply that are rated for outdoor use.
- ▶ To protect against dripping water, route the electric cables through ferrules and connect them without strain to the designated terminals.
- ▶ Ensure correct earthing of the external unit. Never connect the earth lead to gas or water pipes, lightning conductors or telephone earth cables.
- ▶ Use circuit breakers (RCD, disconnecter with B fuse and MCB) with the specified rating.
- ▶ Observe all relevant local and national regulations for electrical installation.

**5.7.2 GENERAL REQUIREMENTS**

Prior to connecting the hybrid manager, ensure that the on-site conditions have been met.

- One 10 A MCB with B characteristics each is provided for the heat source and the hybrid manager.

To prevent inductive influences:

- Route 230 V or 400 V cables separately from LV cables/leads.
- Maintain a minimum clearance of 100 mm.
- Use screened cables where external inductive influences cannot be avoided.

 This screens the cables/leads from external influences, such as HV cables, moving cables, transformer stations, radio and TV appliances, amateur radio stations and microwaves.

To safeguard the splashproof rating (IP):

- Route cables so that the cable sheath protrudes at least 20 mm into the cable entry.

**5.7.3 CONNECTING THE EXTERNAL UNIT**

 **WARNING:** Do not connect the trace heating cable to the electrical connection of the outdoor unit. If this is done severe damage to the outdoor unit will result

 **NOTICE:** Damage from wet conditions! Ingress of rain, humidity or dust can damage the PCB inside the external unit.

- ▶ Never work on the external unit when it is raining.
- ▶ Following work on the terminal strip check that the service cover sits firmly.

 For the power supply and the electrical connection between the external unit and the hybrid manager, select only cables with flexible Neoprene® sheathing to 60245 IEC 57.

- ▶ Route cables through a conduit.

Always pay close attention to safety during all work on the electrical system and components. This includes the following:

**PREREQUISITES**

Prior to connecting the external unit, ensure that the on-site conditions have been met.

- A 16A circuit breaker with type D characteristic and 300mA fault current circuit breaker for AC and DC current at the main distribution board.
- An external isolator switch with at least 3.0 mm contact separation across all poles has been installed near the external unit.

**MAKING THE POWER SUPPLY CONNECTION**

**i** To prevent electrical interference, route all LV cables/ BUS cables separate from 230 V or 400 V cables (minimum clearance 100 mm).

- ▶ Remove the service cover from the external unit.
  - Undo the screw.
  - Remove service cover [3].




Fig. 36 Removing the service cover from the external unit

- [1] Terminal strip
- [2] Earth terminal
- [3] Service cover

- ▶ Connect the power cable to terminal strip [1].




Fig. 37 Power supply to the external unit

- [1] Electrical supply – earth
- [2] Electrical supply – Live
- [3] Electrical supply – neutral

**i** For outdoor use, the three-core power cable for the external unit must have a flexible Neoprene® sheath and a cross-section of at least 1.5 mm<sup>2</sup>. We recommend the use of screened cables, run inside conduits, e.g. LIY CY (TP).

- ▶ Connect the earth cable to the external unit (→ Fig. 38, [1]). Use an earth cable which is longer than the other cables so that it will not become disconnected when strain is applied.

**CONNECTING THE CANBUS CABLE ON THE OUTDOOR UNIT**

**i** For outdoor use, the two-core power cable for the external unit must have a flexible Neoprene® sheath and a cross-section of at least 0.75 mm<sup>2</sup> (at least 0.3 mm<sup>2</sup>).

- ▶ Connect the CANBUS cables from the air to water heat pump control unit to terminals S2 to S3 (→ Fig. 38, [1]).
  - The two wires are not polarity sensitive.




Fig. 38 External unit terminal

- [1] Hybrid manager LV terminals (S2/S3)
- [2] External unit earth cable connection
- [3] Not assigned (S1)

- ▶ Refit the service cover after connection.

**i** If CANBUS cable has been used with earth shielding, connect shielding to point 2

**5.8 INSTALLING THE OUTSIDE TEMPERATURE SENSOR**

**5.8.1 SELECT THE INSTALLATION LOCATION**

The installation location of the outside temperature sensor significantly influences the captured outside temperature and consequently the control of the entire system.

- ▶ Fit the outside temperature sensor at least 4 metres away from any flue terminal or exhaust air vent and the external unit.
- ▶ Mount the outside temperature sensor north facing wall.
- ▶ Select approximately the centre of the height of the building to be heated (generally 2. to 2.5 metres above ground level).

The following installation areas can give false temperature measurements and should therefore be avoided:

- Never mount near windows and doors.
- Never install in poorly ventilated or unventilated areas (e.g. corners, niches).
- Never mount near artificial sources of heat (e.g. external unit air discharge, fans, flue terminals).

**WALL MOUNTING**

- ▶ Drill 2 holes and mount the outside temperature sensor.




Fig. 39 Installing the outside temperature sensor

[a] Clearance between drilled holes: 62 mm

**5.8.2 CONNECTING THE OUTSIDE TEMPERATURE SENSOR**



Refer to the gas boiler installation literature with regards to the wiring connection of the out door sensor to the gas boiler.

- ▶ We recommend the use of screened cables, run inside conduits, e.g. LIY CY (TP).
  - Recommended cross-section: 0.75 mm<sup>2</sup> (≥ 0.5 mm<sup>2</sup>)
  - The two wires are not polarity sensitive.
- ▶ When extending the sensor leads use the following cross-sections:

Lead length [m]	Cross-section [mm <sup>2</sup> ]
20	0.75...1.50
30	1.0...1.50
30	1.50

Table 10 Cross-sections for sensor leads

**5.9 SETTING THE DIP SWITCHES OF THE EXTERNAL UNIT**



The DIP switches are correctly set at the factory. These settings should be checked prior to commissioning.

- ▶ Set or check the DIP switches in accordance with the table 24 on page 52 and Fig 80 page 85.

**6 COMMISSIONING**



**NOTICE:** Incorrect sequence of turning on power to units can cause communication issues between outdoor unit and internal units.

- ▶ Connect all BUS subscribers to the BUS prior to connecting the BUS to the power supply.

**6.1 BEFORE COMMISSIONING**

**6.1.1 SAFETY**

Implement all commissioning steps so that the safety of personnel is ensured at all times and that material losses are prevented. This includes the following:

- ▶ The hybrid system and the components may only be commissioned by a competent person.
- ▶ Never touch the parts of the refrigerant circuit with bare hands during operation. The refrigerant pipes are very hot or very cold depending on the condition of the flowing refrigerant.
- ▶ Never touch any switch or parts of the electrical system with wet hands. There is risk of electric shock.
- ▶ It is vital that the required procedures and waiting periods for switch-on and switch-off are adhered to. Otherwise the hybrid system components could become severely damaged.
- ▶ For commissioning, the power supply to the external unit must be 'live' for at least 12 hours prior to switching the hybrid manager 'live'. If this time frame cannot be achieved, severe damage may occur on the external unit. Never interrupt the power supply during normal operation.
- ▶ The hybrid control module regulates the hours at which the air to water heat pump and the condensing boiler operate, subject to the parameters selected at the FW200.
  - Never interrupt the power supply to the hybrid manager and the external unit during normal operation.
- ▶ Do not interrupt power supply to any units until a minimum of 5 minutes have elapsed since last operation.

**6.1.2 COMMISSIONING REQUIREMENTS**



**WARNING:** Risk of injury through rotating, hot or other components that carry 'live' high voltage.

- ▶ Prior to starting the appliance ensure that all panels, plates and safety equipment has been fitted correctly.

Only operate the hybrid system when all conditions for a safe and intended operation have been met.

- The hybrid manager has been correctly mounted and connected.
- The external unit has been securely positioned, correctly installed and connected.
- The condensate drain of the external unit has been connected.
- The heating system has been flushed and filled to correct operating pressure.
- The refrigerant circuit is correctly installed and has been filled with R410A refrigerant. Tightness has been verified.
- The shut-off valves on the liquid side and the gas side are fully open.
- The electrical connections are correctly made. All essential fuses/ MCBs and safety switches are installed.
- All other system components that are not described here are also installed, connected and ready to operate (→ installation instructions of the components).
- At outside temperatures in excess of 21 °C or below -9 °C, the air to water heat pump will not start in standard mode. Commissioning the heat pump in this temperature range is only possible via the "Service mode" (→ chapter 6.2.24, page 46).

## 6.2 COMMISSIONING THE SYSTEM FOR THE FIRST TIME



**NOTICE:** Damage when starting the compressor in the external unit from cold!

► **For commissioning:**  
The Power supply to the external unit must be "Live" for at least 12 hours before starting operation. This is to ensure that the compressor is warmed up sufficiently to avoid any liquid refrigerant from entering the compressor. This is particularly important during colder periods.  
The 12 hour period also compensates for any unsettling of the lubricating oil within the compressor which may have occurred during transportation. If this 12 hour time period cannot be met damage to the outdoor unit may result.

### 6.2.1 PROVIDING THE EXTERNAL UNIT WITH A POWER SUPPLY AHEAD OF COMMISSIONING

The BUS cable is not connected at this point so the outdoor unit can be powered on for the 12 hour period.

- After the 12 hour period, the power to the outdoor unit can be briefly interrupted (i.e. 5 minutes) to allow connection of the BUS cable to the hybrid manager.
- Once the BUS cable from the outdoor unit has been connected to the hybrid manager the outdoor unit and the hybrid manager can be powered on (within 3 minutes of each other).

### 6.2.2 PROVIDING THE EXTERNAL UNIT WITH A POWER SUPPLY DURING COMMISSIONING

All units must be powered up within a 3 minute time period to prevent any communication issues, therefore there will be a need to interrupt the power supply to the external unit upon commissioning.

### 6.2.3 CONNECTING THE CANBUS CABLE TO THE HYBRID MANAGER UNIT

- Interrupt the power supply to the external unit.
- Undo screws at the top and bottom of the appliance.
- Remove casing.
- Undo fixing screw on the left [1] of the hybrid control module.
- Push out the spring plate [2] and tilt the hybrid control module forward.




Fig. 40 Tilting the hybrid control module forward

- [1] Fixing screw
- [2] Spring plate

- Undo three screws and remove the small cover for the internal connections at the back.




Fig. 41 Removing the small cover

- To provide splashed water protection (IP), always trim the strain relief fitting in accordance with the cable diameter.




Fig. 42 Trimming the strain relief

- Guide the BUS cable through the strain relief fitting and connect it to terminals S2/S3.




Fig. 43 Terminals at the interface to the external unit

- [1] Terminal S2/S3

- Refit the cover after connection.
- Re-establish power supply to external unit

### 6.2.4 MAKING THE POWER SUPPLY CONNECTION

- Connect the 2m pre-installed flexible cable on the hybrid manager unit to the power supply (230 V AC, 3 A).

### 6.2.5 SWITCHING ON THE HYBRID SYSTEM

- Ensure that the shut-off valves on the liquid and gaseous refrigerant pipe work are open.
- Make the power supply to the hybrid manager and the external unit. The external unit's compressor runs for 5 minutes at stage 1 (self-test).



The fan must move freely and not be obstructed.

- Check whether system components start correctly.

**6.2.6 CONNECTING THE PROGRAMMING UNIT TO THE HYBRID CONTROL MODULE**

Use only **one** FW200 programming unit per hybrid system. Connect this to the hybrid control module.

Mount the FW200 programming unit separately on a wall, if the unit has been previously fitted in the front of the boiler unit, it must be removed and fitted externally as stated.

**CONNECTIONS INSIDE THE HYBRID MANAGER**




Fig. 44 Connections at the hybrid manager

- [1] Connections for the ISM CANBUS cable
- [2] Connections for the FW200 programming unit
- [3] Connections for the heat source

- ▶ Remove the front cover of the hybrid control module.
  - Undo fixing screws.
  - Flip up and remove front cover.




Fig. 45 Removing the front cover of the hybrid control module

- ▶ Route the cable through the cable guide behind the insulation.




Fig. 46 Cable guide inside the hybrid manager

- ▶ Connect the two-core CANBUS cable of the FW200 programming unit to terminals 16 and 17 to the hybrid control module and the programming unit.
  - Recommended wire size: 0.75 mm<sup>2</sup> (≥0.5 mm<sup>2</sup>)

Terminals	Connections
14, 15	Additional ISM module unit
16, 17	FW200 programming unit
18, 19	Heat source

Table 11 Connections at the hybrid control module

- ▶ Replace cover when finished.

**6.2.7 CONNECTING THE HEAT SOURCE TO THE HYBRID MANAGER**

- ▶ Route the cable through the cable guide behind the insulation.
- ▶ Connect the two-core CANBUS cable from the heat source to terminals 18 and 19 at the hybrid control module and the heat source.



For Connection's to the heat source always consult the installation manual.

- ▶ Press and hold the back button for approximate 5 seconds to reset the hybrid control module (→ Fig 51, page 44).

**6.2.8 COMMUNICATION ERROR FROM EXTERNAL UNIT ON INITIAL POWER ON OF EXTERNAL UNIT AND HYBRID MANAGER**



It may be necessary to adjust Dip switch SW8-3 on the External Unit controller circuit board if a communication error from the External Unit is present during power on of the External unit and the Hybrid Manager.

It may be necessary to adjust Dip switch SW8-3 on the External Unit controller circuit board if a communication error from the External Unit is present during power on of the External unit and the Hybrid Manager.

Because the Hybrid Manager and External Unit have separate power supplies, it may not be possible for both units to be powered ON at the same time.

The External Unit and Hybrid Manager are separately located and if only one installer is available to switch on both units, the timing to switch ON the External Unit and Hybrid Manager will be different.

If the External Unit is powered ON first, its controller tries to establish the communication with the Hybrid Manager but until the Hybrid Manager is powered ON, the communication cannot be established.

If this status continues for a period of time, the External Unit judges this status as a 'communication error' and this error can not be reset until the External Unit is powered OFF once.

The same thing can happen when the Hybrid Manager is powered on first and the External Unit can not be powered on within a certain period of time.

In order to avoid this 'false' communication error, SW8-3 is available on the External Unit controller circuit board. If switch SW8-3 is set to ON, the Hybrid Manager/External Unit communication error is ignored and the External Unit keeps waiting until the Hybrid Manager is powered ON and responds to the External Unit.

In other words, even though it could take a long time from when the External Unit is powered ON until the Hybrid Manager is powered ON, the communication error is never detected as far as SW8-3 is set ON.

If SW8-3 is NOT set ON, the Hybrid Manager/External Unit communication error will be detected in 3 minutes at the earliest case.

**If you are sure that both the Hybrid Manager and the External unit can be powered on within 3 minutes, you do not need to set SW8-3 ON.**

If the communication error is caused not only by this power supply issue but by electrical noise etc, the error can be detected by the indoor board side even if SW8-3 is ON and the error code can be displayed on the FW200.

### 6.2.9 ADJUSTING THE HYBRID MANAGER CIRCULATING PUMP IN THE HYBRID MANAGER

The Hybrid manager circulating pump in the hybrid manager is set subject to the system configuration.

#### ADJUSTING THE HYBRID MANAGER CIRCULATING PUMP CURVE

The Hybrid manager circulating pump can be set up in different ways:

- I Constant pressure curve, speed stage I
- II Constant pressure curve, speed stage II
- III Constant pressure curve, speed stage III.



Constant pressure curve, speed stage III is the standard setting. Pump must be used in fixed speed mode only.

- ▶ Select and set the speed stage in line with the procedures described in section 6.2.9
- ▶ Press arrow button [1] on the Hybrid manager circulating pump to select the required stage.




Fig. 47 Setting the speed stage at the HE pump



Set the Hybrid manager circulating pump to the lowest speed stage possible subject to system pressure drop. We recommend speed stage II or III.

### 6.2.10 SYSTEM WITH SERIES BUFFER TANK

Does the installation have a single or a multi heating circuit with a serial buffer tank? As shown in Fig. 7 8, 9 and 10.

1. The pump in the accessory box should be set on Constant Speed III, II or I.  
The pump should be set on the lowest setting which matches P the Total System Pressure Drop.
2. The Available Pump Head, see figure 49 (Available head), must overcome A the Heating Circuit Resistance and B the resistance of any Additional Pipe work between the Accessory Box and the heating system
3. What is the maximum condensing boiler heat output Q for the heating system in kW?
4. What is T the required design Delta T (Flow temperature - Return temperature) across the system?




**NOTICE:** The typical design Delta T is 20K

5. What is V the required system flow rate to achieve T the design Delta T at the maximum CH heating output Q?  
 $V = 14.3 \times Q / T$
6. What is the pressure drop of the heating circuit at flow rate F [l/min] in mbar?
7. What is the equivalent length of additional 22mm pipe work between the Accessory Box and the heating system in metres?



**NOTICE:** The equivalent length of pipe work includes all additional pipe work bends (an elbow is equivalent to 1m length of pipe work)


8. What is B the pressure drop of the equivalent length of additional pipe work in mbar? - refer to figure 48, Pressure drop/Flow rate
9. Calculate P the Total System Pressure Drop that the pump needs to overcome,  $P = A + B$
10. From Available Hydraulic Pump Head Chart, refer to figure 49, select the closest pump setting which provides P the Total pressure at F the system flow rate.
11. If none of the pump curves match the requirement it may be necessary to reduced B the equivalent length of additional pipe work



6720646970-130.1Wo

Fig. 48 Pressure and flow rate in the hybrid manager (internal unit)

- [1] System flow rate (litres/min)
- [2] Pressure drop of 22mm OD copper pipe (mbar/metre)
- [P] = Total System Pressure Drop - mbar
- [A] = Heating Circuit Resistance - mbar
- [B] = Additional pipe work - metres
- [Q] = Maximum Boiler Heating Output -kW
- [T] = Delta T (Temperature drop between flow and return) -K
- [F] = System Flow rate - litres/minute



6720803687-07.1Wo

Fig. 49 Available pump head

- [I] Constant pressure curve for speed stage I
- [II] Constant pressure curve for speed stage II
- [III] Constant pressure curve for speed stage III
- [3] Available pump head - mbar
- [4] System flow rate - litres/minute

**6.2.11 VENTING THE HYBRID MANAGER**

 **NOTICE:** Damage through pump running dry!  
▶ Regularly check the water level and top up heating system with water, if required.

 We recommend the installation of a manual air vent valve near the heating water return of the hybrid manager to enable the hybrid manager to be vented.

 Airlocks in the pump can result in noise, vent the circulating pump to remove any air lock.

- ▶ Open manual air vent valve.
- ▶ Close the manual air vent valve as soon as there is sign of water present. This prevents air being drawn into the system again.
- ▶ Select Hybrid manager circulating pump speed stage III.
- ▶ Select the “Function test” menu at the FW200 programming unit, in order to operate the Hybrid manager circulating pump (→ Operating instructions of the FW200 programming unit).
- ▶ Let the Hybrid manager circulating pump run for a short time, subject to system layout and size.
- ▶ Stop the Hybrid manager circulating pump via the “Function test” menu.
- ▶ Open manual air vent valve.

 Reinststate the specified system pressure if a large amount of air escapes from the system.

- ▶ Close the manual air vent valve.
- ▶ Repeat steps 3 to 8 until the system has been completely vented.
- ▶ After venting the system, adjust the pump (→ section 6.2.9).

**6.2.12 SETTING THE BYPASS VALVE**

 Once the bypass valve is set it is recommended to lock the valve setting in place.

Set the bypass valve subject to the selected pump curve:

- Speed stage I  
⇒ bypass setting = 0.05 bar
  - Speed stage II  
⇒ bypass setting = 0.18 bar
  - Speed stage III  
⇒ bypass setting = 0.45 bar
- ▶ Select the determined bypass setting at the adjusting part of the bypass valve.




Fig. 50 Setting the bypass valve

**6.2.13 SETTING PARAMETERS FOR OPTIMISING ENERGY USE AND COSTS OF THE HYBRID SYSTEM**

 These parameters can be set either via the FW200 programming unit or via the hybrid control module. These values are transferred and overwritten respectively. The following explains the setting using the FW200 programming unit. For information on setting at the hybrid control module, see chapter 6.2.23.

The hybrid system offers a choice of different operating modes:

Operating mode	Description
Environmental factors	With CO <sub>2</sub> -optimised mode, the system control decides when operating the air to water heat pump or the condensing boiler results in the greatest CO <sub>2</sub> reduction.
Costs	With the cost-optimised operation, the system control decides on the basis of current energy prices. Rising gas prices result in longer operation of the air to water heat pump, whilst rising electricity prices result in longer operation of the condensing boiler.
Environment and costs	Mixed operation taking environmental factors and costs into account. Environmental and financial aspects are taken into consideration.
Changeover threshold	With weather-compensated operation, the condensing boiler starts from a set outside temperature.

Table 12 Overview of operating modes

### 6.2.14 EXPLANATION OF THE PARAMETERS FOR ENERGY AND COST OPTIMIZATION OF THE HYBRID SYSTEM (CONTROL STRATEGY)



These parameters can be set either via the FW 200 weather compensated controller or via the hybrid control module. These values are transferred and overwritten respectively. The following section will describe how to make the settings using the FW 200 weather-compensated controller. For information on making settings on the hybrid control module, see chapter 6.2.23.

The hybrid system offers a choice of selecting between different control strategies:

#### CONTROL STRATEGY: CO2 OPTIMISED

The CO2-optimised mode (factory setting) uses environmental factors to determine when the heat pump or boiler is to be operated to achieve the highest CO2 reduction.

The environmental factors for fossil fuel and electricity must be set. The environmental factor (or primary energy factor, PEF) indicates the fossil-fuel consumption incurred until the energy (electricity/gas) is available at the corresponding heat appliance. A heat pump uses the input energy more efficiently than a boiler. However, the electricity used generally involves a larger amount of fossil-fuel consumption. The following statement applies to both environmental factors: the lower the values, the better this is for the environment.

#### Examples:

Electricity from a gas-fired power station that runs at 45 % efficiency has an environmental factor of:

- $1/45 \% = 1/(45/100) = 1/0,45 = 2,2$ .

**Mix** with an efficiency of 38.4% has an environmental factor by:

- $1/38,4 \% = 1/(38,4/100) = 1/0,384 = 2,6$ .

**Natural gas**, which is supplied with a loss of 12% (88% efficiency), has an environmental factor of:

- $1/88 \% = 1/(88/100) = 1/0,88 = 1,1$ .



The actual environmental factor for the available energy (electricity/gas) must be checked with the energy supplier.

#### CONTROL STRATEGY: COST OPTIMISED

With the cost-optimised mode, the system control decides on the basis of current energy prices. Rising gas prices result in longer operation of the heat pump, whilst rising electricity prices result in longer operation of the boiler.

The cost ratio is the difference between Gross electricity and gas prices converted to Nett.

#### Example:

- Cost of electricity: 24 p/kwH
- Cost of Gas: 8 p/kwH

Cost ratio (net):  $(24/8) \times 0.902 = 2.7$

This is the ratio which must be inputted to the system controller.

This conversion can be made using table 47 on page 82 of this manual.



The energy:price ratio for electricity and fossil fuel must be adjusted regularly to the actual price ratios. The appendix includes the weighting factors for different electricity and gas prices (chapter 13.1, page 82, table 47).

#### CONTROL STRATEGY: CHANGEOVER

In weather-compensated mode, the boiler delivers the entire heating energy below a set outside temperature (dual mode changeover threshold). The heat pump is not in operation.

At temperatures above the set outside temperature, the heat pump delivers the entire heating energy where possible. The boiler is operational when the heat output of the heat pump is not sufficient to cover the heat load.

#### CONTROL STRATEGY: CO2 COST MIX

Mixed operation of environmental factors and cost.

The environmental factors and the energy price ratio are considered. Information under the control strategy: CO2 optimised and control strategy: Cost-optimised, note on page 41.

**INSTALLER SETTINGS: HYBRID MENU**

The parameters for the selected control strategy of the hybrid system are set in the room controller or the Hybrid Manager.

Knowledge of the following operations should be conveyed to the user at hand over:

- Basic principles of operation
- Commissioning
- General settings for the heating system





Operation	Display
<p>Normal view of FW200 when running in auto</p> <p>► Open the flap (by pulling the recessed grip on the front).</p>	
<p> menu</p> <p>Press for 3 seconds</p>	<p><b>INSTALLER SETTINGS</b> menu appears</p> 
<p> Turn</p>	<p>Scroll down to the <b>Hybrid</b> entry</p> 
<p> Press</p>	<p>The <b>HYBRID SETTINGS</b> menu appears</p> <p>Menu items:</p> <ul style="list-style-type: none"> <li>• <b>Control strategy</b> <ul style="list-style-type: none"> <li>- CO2 - optimised</li> <li>- Cost - optimised</li> <li>- Changeover temperature</li> <li>- CO2 :cost mix</li> </ul> </li> <li>• *Energy: Price ratio</li> <li>• *Environmental factor for fossil fuel (1.1)</li> <li>• *Environmental factor for electricity (2.6)</li> <li>• Hydraulic connection (factory default, do not adjust)</li> <li>• Delay time for boiler heating</li> <li>• Temperature differential for boiler switch ON</li> </ul> 

Table 13 Hybrid settings menu

\* May or may not be available dependent on control strategy selected

**6.2.15 CONTROL STRATEGY: OPTION CO2 OPTIMISED AND CO2 :COST MIX**

Operation is dependent on a number of factors all of which must be discussed and agreed to with the customer.



Operation	Display
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy &gt;</b> (→ Table 13)</li> <li>▶ Select <b>Control strategy</b> from the menu</li> <li>▶ Confirm the selected menu item</li> <li>▶ Adjust chosen option, for example, <b>CO<sub>2</sub> : optimised</b> (description of options → page 39).</li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>	
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy &gt;</b> (→ Table 13)</li> <li>▶ Select <b>Control strategy</b> from the menu</li> <li>▶ Confirm the selected menu item</li> <li>▶ Adjust chosen option, for example, <b>CO<sub>2</sub> :cost mix</b> (description of options → page 39).</li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>	

Table 14 Adjust control strategy

**6.2.16 CONTROL STRATEGY: CO2 OPTIMISED (ENVIRONMENTAL FACTORS)**

For this control strategy the parameters, Environmental factor electrical energy and Environmental factor fossil fuel must be set


Operation	Display
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy &gt;</b> (→ Table 13)</li> </ul> <p>If previously adjusted <b>CO<sub>2</sub> optimised</b> menu, the controller will move to <b>environmental factors electricity/gas</b></p> <ul style="list-style-type: none"> <li>▶ Select <b>Energy: price ratio</b> from the menu</li> </ul>	
<ul style="list-style-type: none"> <li>▶ Confirm the selected menu item</li> </ul>	
<ul style="list-style-type: none"> <li>▶ Required value: <ul style="list-style-type: none"> <li>- Setting range: 0.0 to 5.0</li> <li>- Default environmental factor for fossil fuel: 1.1 (natural gas)</li> <li>- Default environmental factor for electrical energy: 2.6 (mix)</li> </ul> </li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>	

Table 15 Set environmental factor for electricity and fossil fuel

**6.2.17 CONTROL STRATEGY: CO2: COST MIX**

For this control strategy the Energy: Price ratio and the environmental factors for both fossil fuel and electricity must be set.

Operation	Display
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy</b> &gt; (→ Table 13)</li> <li>If <b>CO<sub>2</sub>:cost mix</b> is selected the controller will then display the following menu items.</li> <li>• <b>Energy: price ratio</b></li> <li>• <b>Environmental factor fossil fuel</b></li> <li>• <b>Environmental factor electrical energy</b></li> <li>▶ Select and adjust each of the menu items to the require values</li> </ul>	
<ul style="list-style-type: none"> <li>▶ Confirm the selected menu item</li> </ul>	
<ul style="list-style-type: none"> <li>▶ Required value:</li> <li>• <b>Energy: price ratio</b> <ul style="list-style-type: none"> <li>- Setting range: 0.0 to 19.9</li> <li>- Default: 3.3</li> </ul> </li> <li>• <b>Environmental factor fossil fuel</b> <ul style="list-style-type: none"> <li>- Setting range: 0.0 to 5.0</li> <li>- Default: 1.1</li> </ul> </li> <li>• <b>Environmental factor electrical energy</b> <ul style="list-style-type: none"> <li>- Setting range: 0.0 to 5.0</li> <li>- Default: 2.6</li> </ul> </li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>	

Table 16 Energy price ratio and environmental factors for fossil fuel and electricity set.

**6.2.18 CONTROL STRATEGY: OPTION CHANGEOVER TEMPERATURE**

For this control strategy, the parameter changeover are set correctly.

Operation	Display
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy</b> &gt; (→ Table 13)</li> <li>▶ Select <b>changeover temperature</b> from the menu</li> </ul>	
<ul style="list-style-type: none"> <li>▶ Confirm the selected menu item</li> </ul>	
<ul style="list-style-type: none"> <li>▶ Required value:</li> <li>- Setting range: -20° to 20°</li> <li>- Default: 6°</li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>	

Table 17 Outdoor temperature for switching threshold set

**6.2.19 CONTROL STRATEGY: COST OPTIMISED**

For this strategy the energy: Price ratio is required (chapter 13.1, page 82, table 47).

**6.2.20 CONTROL STRATEGY: HYDRAULIC CONNECTION**

This determines the function of the pump in the Hybrid Manager.

Pump Function	Description
<b>Serial</b> (factory default)	The pump provides water circulation around the central heating circuit(s) - used for all hydraulics described in this document
<b>Parallel</b>	The pump does not provide water circulation around the central heating circuit(s). For this type os system each heating circuit has its own pump. (not possible with this system).

Table 18 Hydraulic connection preset

**6.2.21 CONTROL STRATEGY: DELAY TIME FOR BOILER HEATING**

The delay time of the boiler starting if (requested system flow set temperature - requested heat pump flow set temperature) is equal to or less than the set Delta T.

**Set time delay.**

Operation
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy</b> &gt; (→ Table 13)</li> <li>▶ Select <b>Delay time for boiler heating</b> from the menu</li> </ul>
<ul style="list-style-type: none"> <li>▶ Confirm the selected menu item</li> </ul>
<ul style="list-style-type: none"> <li>▶ Required value:                             <ul style="list-style-type: none"> <li>- Setting range: 5 to 120</li> <li>- Default: 20</li> </ul> </li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>

*Table 19 Delay time for boiler heating set*

**6.2.22 CONTROL STRATEGY: TEMPERATURE DIFF FOR BOILER SWITCH ON**

The temperature difference between the system flow set point temperature and the heat pump flow set point temperature.

**Set the Delta T.**

Operation
<ul style="list-style-type: none"> <li>▶ <b>HYBRID SETTINGS&gt; Control strategy</b> &gt; (→ Table 13)</li> <li>▶ Select <b>Temperature for boiler switch ON</b> from the menu</li> </ul>
<ul style="list-style-type: none"> <li>▶ Confirm the selected menu item</li> </ul>
<ul style="list-style-type: none"> <li>▶ Required value:                             <ul style="list-style-type: none"> <li>- Setting range: 1K to 99K</li> <li>- Default: 3K</li> </ul> </li> <li>▶ Confirm set value</li> </ul> <p>The controller works with the new settings.</p>

*Table 20 Temperature differential for boiler switch on set*

**6.2.23 SETTING PARAMETERS AT THE HYBRID CONTROL MODULE**




Fig. 51 Control module of the hybrid manager

- [1] Fuse, 5 AT, ceramic, filled with sand
- [2] Spare fuse
- [3] Service key connection
- [4] Rotary selector: turn to scroll, push to select
- [5] Display
- [6] Back button

Display [5] shows the current status/display code or parameter list. This can be recognised by the letters on the right hand side of the display.

- “c”: Parameter list
- “e”: Status/display code
- ▶ With the “Back button”, change between the current status/display code and parameter list.
- ▶ Scroll through the parameter list with the “Rotary selector”.
- ▶ Push “Rotary selector” to select any parameter.  
The selected parameter begins to flash.
- ▶ Set the required value by turning the “Rotary selector”.
- ▶ Push “Rotary selector” to confirm and save the new parameter setting.

Display code	Description	Unit	Standard setting	Input range	
Aa	Setting the hydraulic system	—	0	0 = In series 1 = In parallel (not possible with this system)	This determines the function of the pump in the Hybrid Manager. 0= the pump provides water circulation around the central heating circuit(s) - used for all hydraulics described in this document, 1= the pump does not provide water circulation around the central heating circuit(s), for this type of system each heating circuit has its own pump.
Ab	Heat source delay	min	20	5 - 120	The HTH (high temperature heat source) delay time given to the boiler if; (The required system flow temperature – the actual system flow temperature) is equal to or less than the set Delta T.
Ac	Heat source delay temperature	K	3	1 - 99	The delta temperature used by the delay timer. The temperature difference between the required system flow temperature and the actual system flow temperature that will activate the delay time.
A5	External unit control interval	min	1	1 - 30	The time interval at which the set point is re-calculated, based on changing external influences.

Table 21 Parameter list of the hybrid control module

Display code	Description	Unit	Standard setting	Input range	
A7	Temperature differential towards the heat source to prevent the defrost function	°C	10	7 - 10	This is the minimum outside air temperature at which the outdoor unit can be operated in order to avoid going into a defrost mode. Because a buffer tank must always be installed in the system, defrost operation can always be allowed and the outdoor unit can operate between -9 to +21 °C outside air temperature.
C0	Buffer cylinder is being used.	—	—	—	A buffer tank must always be installed in the system. Function not available in the UK
C1	Environmentally- and cost-optimised operation.	—	1	1 = Environmental factors 2 = Costs 3 = Changeover threshold 4 = Environment and costs	This determines how the control strategy is optimised
C2	Dual mode changeover threshold	°C	6	-20 - 20	If the "Bi-valent set point" control strategy is selected, this is the outside air temperature below which the Outdoor unit has to be switched off
C3	Cost weighting electricity price—gas price.	—	3.3	0 - 19.9	The energy price ratio = cost of electricity, P/kWh / cost of gas, P/kWh. Use the look up table to find the energy price ratio based on energy prices (see table 47 on page 82)
C4	Environmental factors - gas.	kWh/kWh	1.1	0 - 5	Primary energy factor for gas = total primary energy consumed in the generation and distribution, kWh / 1kWh of energy used based on gas
C5	Environmental factors - electricity.	kWh/kWh	2.6	0 - 5	Primary energy factor for electricity = total primary energy consumed in the generation and distribution, kWh / 1kWh of electrical energy used
5b	Return to the standard setting.	—	0	1 = Reset 0 = Off	This resets all parameters to factory settings
5c	Service mode for commissioning at an outside temperature above 21 °C or below -9 °C.	—	0	1 = On 0 = Off	When the Hybrid system is in normal use the outdoor unit can operate between an outside air temperature of -9 to +21 °C. During commissioning of the system the outdoor unit is allowed to operate outside of this range using the "service" function.
tt	Factory test mode - leave set to "0", when set to "1" the Hybrid controller will not function for 15 minutes or until the power has been turned off and on again.	—	0	0 = Normal operation 1 = Test mode	

Table 22 Parameter list of the hybrid control module

### 6.2.24 COMMISSIONING OF THE AIR TO WATER HEAT PUMP AT OUTSIDE TEMPERATURES OUTSIDE THE STANDARD OPERATING RANGE

The air to water heat pump must only be commissioned if the entire system, including condensing boiler, is connected and ready for operation. At outside temperatures in excess of 21 °C or below -9 °C, the air to water heat pump will not start in standard mode, as there is no heat demand [for the heat pump] in this temperature ranges.

The "Service mode" function of the hybrid control module enables the air to water heat pump to be commissioned outside the standard operating temperature range.

Setting "Service mode" at the hybrid control module:

- ▶ Press "Back" until the parameter list is displayed. ("c" is displayed on the right hand side of the display).
- ▶ Turn "Rotary selector" until "5C" is displayed.
- ▶ Push "Rotary selector" once. default "0" begins to flash.
- ▶ Turn the "Rotary selector" to change the value to "1".
- ▶ Press the "Rotary selector" to set the value. "Service mode" is now activated.



"Service mode" resets automatically after 20 minutes.



The air to water heat pump only starts if the return temperature lies between 20 °C and 50 °C. It may be necessary for the condensing boiler to initially raise the return temperature to 20 °C before the air to water heat pump can start.

### 6.2.25 INFORMING THE CUSTOMER AND HANDING OVER THE TECHNICAL DOCUMENTS

- ▶ Make your customer familiar with the entire heating system and the operating instructions of the hybrid system.
- ▶ Turn the system off and then back on to show your customer how the unit works.
- ▶ Using the operating instructions, explain to your customer how to act in case of emergencies. e.g. when there is a fire.
- ▶ Hand over the technical documents to your customer and together with your customer complete the separate commissioning report and sign it.

## 7 OPERATION

The hybrid control module regulates the hours at which the air to water heat pump and the condensing boiler operate, subject to the parameters selected at the FW200.

- ▶ Never interrupt the power supply to the hybrid manager and the external unit during normal operation.

### 7.1 AUTOMATIC DEFROST FUNCTION

At low temperatures ( $\geq 7$  °C), ice forms on the external unit.

In the outside temperature range from +7 °C to -9 °C the heat from the heating system water is briefly used to defrost the external unit automatically. During defrosting, the heat source continues to be available for heating the heating water.

The defrost process takes approximately 5 minutes.

### 7.2 SYSTEM SHUTDOWN



#### NOTICE: Frost damage!

When the heating system is switched off, it can freeze up if there is a frost.

- ▶ In case of a risk from frost, protect the heating system against frost damage. To do so, drain the heating water at the lowest drain point of the heating system. When draining also ensure that the air vent at the highest point in the heating system is open.

#### 7.2.1 REGULAR SYSTEM SHUTDOWN



The hybrid manager regulates the hours at which the air to water heat pump and the condensing boiler operate, subject to the parameters selected at the FW200 programming unit or at the hybrid control module.

- ▶ Never interrupt the power supply to the hybrid manager and the external unit during normal operation.

Taking the hybrid system out of use:

- ▶ Ensure any current or pending heat demands are removed. To do this switch the FW200 room controller to frost protection mode (refer to FW200 installation manual) and allow the system to stop under it's own control.
- ▶ When the system has stopped, wait at least 5 minutes before interrupting the power supply to the hybrid manager. The hybrid manager, outdoor unit or the boiler could be damaged if the unit is switched off before 5 minutes of idle time.

#### 7.2.2 SYSTEM EMERGENCY SHUTDOWN



Only interrupt power via the installation room fuse/circuit breaker in emergencies.

For any other purpose follow the procedure described above.

Explain to your customer how to act in case of emergencies, e.g. when there is a fire or when refrigerant escapes.

- ▶ Never risk your own life. Your own safety is paramount.
- ▶ Close the main fuel shut-off valve. Only if safe to do so.
- ▶ Isolate the heating system from the mains power supply by means of the heating system emergency stop switch or the appropriate domestic fuse/circuit breaker. Only if safe to do so.

### 7.3 RESTARTING THE HYBRID SYSTEM AFTER AN INTERRUPTION IN OPERATION



**NOTICE:** Damage to the external unit from low compressor operating temperature!  
The Power supply to the external unit must be "Live" for at least 12 hours before any heating demand. This is to ensure that the compressor is warmed up sufficiently to avoid any liquid refrigerant from entering the compressor. This is particularly important during colder periods. The 12 hour period also compensates for any unsettling of the lubricating oil within the compressor which may have occurred during transportation. If this 12 hour time period cannot be met damage to the outdoor unit may result.

- ▶ Never interrupt the power supply during normal operation.

- ▶ Ensure that the shut-off valves on the liquid and gaseous refrigerant pipe work are open.
- ▶ If not already, interrupt the power supply to the hybrid manager and the external unit.
- ▶ Undo the outer case screws at the top and bottom of the hybrid manager (Fig. 23, page 25) and lift off the case.
- ▶ Undo fixing screw on the left hand. side of the hybrid control module (→ Fig. 40, page 33).
- ▶ Push out the spring plate and tilt the hybrid control module forward.
- ▶ Undo two screws and remove the small cover at the back (→ Fig. 41, page 33).
- ▶ Disconnect the BUS cable at terminals S2/S3 (→ Fig. 43, page 33).

## 8 ENVIRONMENTAL PROTECTION/DISPOSAL

Environmental protection is one of the fundamental company policies of the Bosch Group.

Quality of products, efficiency and environmental protection are equally important objectives for us. Laws and requirements aimed at protecting the environment are strictly adhered to.

To protect the environment we will, subject to economical aspects, use the best possible technology and materials.

### PACKAGING

We participate in the recycling programmes of the countries in which our products are sold to ensure optimum recycling.

All of our packaging materials are environmentally compatible and can be recycled.

### 8.1 DISPOSING OF REFRIGERANT

The appliance is charged with R410A refrigerant.

R410A is a greenhouse gas. It must not enter the environment.



**CAUTION:** Incorrect disposal is an environmental hazard!  
Escaping refrigerant damages the environment.

- ▶ Refrigerant may be disposed of by qualified installers only.

- ▶ If you wish to discard refrigerant, please contact your local authorities and ask for the correct method of disposal.

### 8.2 APPLIANCE DISPOSAL

Old appliances contain valuable materials that must be recycled.

The appliance is marked with the  symbol.



Appliances with this symbol may not be disposed of with domestic waste at the end of their service life.

- ▶ Sort and dispose of packaging materials according to the your local recycling system.
- ▶ Have this appliance and any accessories disposed of in accordance with locally applicable regulations by a licensed contractor.
- ▶ Never dispose of the appliance in the normal refuse (dust bin).
- ▶ If the appliances have batteries or rechargeable batteries, dispose of these separately beforehand according to local regulations.
- ▶ Dispose of electric and electronic equipment separately according to local requirements.

## 9 INSPECTION AND MAINTENANCE

### HANDLING REFRIGERANT



Compared to previously used refrigerants, the R410A refrigerant operates at a pressure that is approx. 1.6-times higher.

- ▶ Only qualified and authorised refrigeration engineers may work on the refrigerant system.
- ▶ During installation work, use the tools and components specifically designed for handling R410A refrigerant.
- ▶ Check for leaks in the refrigerant system. Escaping refrigerant coming into contact with a naked flame will produce poisonous gases.
- ▶ Never release refrigerant to the atmosphere.

If refrigerant leaks and touches the skin, it can cause frostbite.

- ▶ In case of a refrigerant leak, never touch any part of the air to water heat pump.
- ▶ Avoid skin or eye contact with refrigerant.
- ▶ Seek medical attention if you get refrigerant on your skin or in your eyes.

### 9.1 PREPARING FOR INSPECTION AND MAINTENANCE



**DANGER:** Danger to life through electric shock!  
▶ Before carrying out work on electrical components, isolate them from the power supply (230 V AC) (fuse, circuit breaker) and secure against unintentional reconnection.



**WARNING:** Risk of injury and material losses through incorrect inspection and maintenance.  
▶ The hybrid system, the heat source and the components may only be sited and installed by the manufacturer or an authorised contractor.  
▶ Any service work on the refrigerant circuit must be carried out by an F-Gas qualified refrigeration engineer whose employer is F-Gas certified.

To ensure low energy consumption and environmental impact over the long term, we recommend arranging a maintenance service at a regular interval of 12 months.

All inspection and maintenance activities must be carried out in such a way that personal safety is ensured and damage to property is avoided. This includes the following:

- ▶ Shut off the gas supply prior to any work on the heat source.
- ▶ Isolate the system from the power supply.


**For commissioning:**

The Power supply to the external unit must be "Live" for at least 12 hours before starting operation. This is to ensure that the compressor is warmed up sufficiently to avoid any liquid refrigerant from entering the compressor. This is particularly important during colder periods. The 12 hour period also compensates for any unsettling of the lubricating oil within the compressor which may have occurred during transportation. If this 12 hour time period cannot be met damage to the outdoor unit may result. arranged, severe losses may occur on the external unit.

- ▶ Switch the power supply to the external unit 'live' for at least 12 hours prior to switching the hybrid manager 'live' (→ chapter 6.2.1, page 33).

- ▶ Never touch the parts of the refrigerant circuit with bare hands during operation. The refrigerant pipes are very hot or very cold depending on the condition of the flowing refrigerant.
- ▶ Never touch any switch or parts of the electrical system with wet hands. There is risk of electric shock.
- ▶ Observe the specified processes and delays when starting and stopping the system. Inappropriate ramping down of the appliance can result in damage.
- ▶ After stopping operation, wait at least 5 minutes. Interrupt the power supply to the hybrid manager and the external unit no sooner. Damage may occur through escaping water or appliance faults if the [specified] delays are not observed.

**9.3 MAINTENANCE INTERVALS**

Step	Maintenance interval	Description
Heat source	→ Maintenance instructions of the heat source	
Visual inspection of the hybrid manager	Annual	→ Chapter 9.4.1
Cleaning filters in the hybrid manager	Annual	→ Chapter 9.4.3
Visual inspection of external unit	Annual	→ Chapter 9.5.2
Cleaning the external unit air intake	Annual	→ Chapter 9.5.3

Table 23 Maintenance and maintenance intervals



If any condition requiring maintenance is identified in the course of the inspection, that work must be carried out as required.

**9.2 ENTER INTO AN INSPECTION AND MAINTENANCE CONTRACT**

- ▶ After replacing components, always check for leaks in the refrigerant circuit and carry out function tests.
- ▶ Any O-ring or gasket that appears damaged must be replaced.
- ▶ When reassembling the hydraulic parts, ensure there is no dust or debris stuck to the O-rings.
- ▶ Tighten all connections thoroughly after service to avoid any water leaks and stop connections from coming loose during operation.
- ▶ Check all bolts, screws and cables are assembled correctly before starting the system after any service work has been carried out.
- ▶ When the work is finished, reset the controls to the original settings.

## 9.4 MAINTAINING THE HYBRID MANAGER

### 9.4.1 VISUAL INSPECTION OF THE HYBRID MANAGER

- ▶ With the hybrid manager running, pay attention to any unusual noise.
- ▶ Check the insulation of the refrigerant lines in the hybrid manager for damage and repair if required.
- ▶ Check the hybrid manager and pipe work for possible damage.
- ▶ If the hybrid manager is located inside a compartment or cupboard, ensure that the specified minimum service clearances are maintained.
- ▶ Check all joints in the entire system and replace any leaky connections.
- ▶ Check the fill pressure and possibly top up heating water.
- ▶ Call up fault displays at the FW200 programming unit (→ Operating instructions of the FW200 programming unit).

### 9.4.2 DRAINING THE HEATING WATER FROM THE HYBRID MANAGER



**NOTICE:** Water damage. Escaping water can damage the appliance and electronic components.

- ▶ Prior to starting maintenance or repair work, always drain the water from the hybrid manager.



The hybrid manager contains approximately 1.4l of water.

- ▶ Ensure no current or pending heat demands are active and the unit is in idle.
- ▶ Remove the outer case from the hybrid manager (Fig. 23, Page 25)
- ▶ Undo the retainer screw and lower the control panel. (Fig 54, Page 49)
- ▶ Remove the front upper insulation (Fig. 55, Page 50) being careful not to misplace the small piece of insulation at the side of the pump.
- ▶ Close all of the shut off valves on the hybrid manager water connections (Fig. 52, Page 49).
- ▶ Remove the drain hose from the front of the lower insulation.
- ▶ Remove the lower insulation (fig 56, Page 50).
- ▶ Push the drain hose onto the drain valve (fig 53, Page 49).




Fig. 52 Closing shut-off valves on the hybrid manager

- ▶ Turn the wing screw [1] one ¼ turn anti-clockwise to open the drain valve.  
The pressurised portion of heating water escapes from the hybrid manager.




Fig. 53 Draining water from the hybrid manager

- ▶ Open one of the threaded joints between the shut-off valve and the hybrid manager.  
This drains the remaining water leaving the hybrid manager free of water.

### 9.4.3 CLEANING THE FILTER



**NOTICE:** Damage through incorrect cleaning.

- ▶ Care should be taken when removing the filter as to not to damage this.

Clean the hybrid manager filter annually.

- ▶ Remove the front cover of the hybrid manager.
- ▶ Undo fixing screw on the left [1] of the hybrid control module.
- ▶ Push out the spring plate [2] and tilt the hybrid control module forward.




Fig. 54 Tilting the control unit forward

- [1] Fixing screw
- [2] Spring plate

- ▶ Remove top insulation panel.




Fig. 55 Removing the top insulation panel

- ▶ Remove bottom insulation panel.




Fig. 56 Removing the bottom insulation plate

- ▶ Turn the filter assembly handle forward into the horizontal position.




Fig. 57 Turning the filter assembly handle forward

- ▶ Undo and remove filter cover [1].
- ▶ Remove the filter circlip.

- ▶ Remove the filter and clean using fresh water.




Fig. 58 Removing the filter

[1] Filter cover

- ▶ Replace the filter and re-assemble the unit following the above in reverse.

#### 9.4.4 CHECKING THE TEMPERATURE SENSOR

- ▶ Check the position and condition of the following temperature sensors:
  - Temperature sensor at the condenser inlet [1].
  - Temperature sensor at the condenser outlet [3].
  - Temperature sensor at the pipe work for liquid refrigerant [2].




Fig. 59 Position of temperature sensors

#### 9.4.5 COMPLETING INSPECTION AND MAINTENANCE

- ▶ Install casing parts.
- ▶ Complete and sign the inspection and maintenance report in this manual (→ Chapter 9.6).

## 9.5 SERVICING THE EXTERNAL UNIT

 **DANGER:** Risk to life due to escaping refrigerant. Escaping refrigerant can result in asphyxiation and frost bite in the case of contact at its exit point.

- ▶ When refrigerant escapes, never touch any components of the air to water heat pump and ensure adequate fresh air ventilation.
- ▶ Avoid skin or eye contact with refrigerant.
- ▶ Seek medical attention if you get refrigerant on your skin or in your eyes.

 **NOTICE:** Damage from wet conditions! Ingress of rain, humidity or dust can damage the PCB inside the external unit.

- ▶ Never work on the external unit when it is raining.
- ▶ Following work on the terminal strip check that the service cover sits firmly.

### 9.5.1 GENERAL NOTES

The system uses R410A refrigerant only.

- ▶ Only qualified and authorised refrigeration engineers may work on the refrigerant system.
- ▶ During installation work, use the tools and components specifically provided for handling R410A refrigerant.
- ▶ Check for leaks in the refrigerant system. Escaping refrigerant coming into contact with a naked flame will produce poisonous gases.
- ▶ Never release refrigerant to the atmosphere.

### 9.5.2 VISUAL INSPECTION OF EXTERNAL UNIT

 Chapter 10 includes an overview of fault displays.

- ▶ With the external unit running pay attention to any unusual noise.
- ▶ Check for signs of corrosion and worn or damaged parts. Pay particular attention to refrigerant lines, insulation and connections.
- ▶ Check for loose fasteners.
- ▶ Check for blocked condensate drain or damaged trace heating cable in the condensate pan.
- ▶ Check for contamination and clean or repair, if required.
- ▶ External unit faults are signalled by LED1 (green) and LED2 (red) on the PCB in the external unit.
- ▶ Clean away any obstructions i.e. leaves

### 9.5.3 CLEANING THE EXTERNAL UNIT AIR INTAKE

 **NOTICE:** Damage through incorrect cleaning.

- ▶ Carefully brush off dirt by hand or with a soft brush.
- ▶ Never use high pressure cleaners or water hoses for cleaning the external unit.
- ▶ If cleaning by hand wear gloves to protect your hands.
- ▶ Do not use any cleaning products that are abrasive or contain acid or chlorine.

- ▶ Check evaporator fins and air intake at the rear and the left hand side of the external unit and clean, if required. Clearing any obvious obstructions (i.e. leaves)
- ▶ Switch off the external unit at the on/off switch.
- ▶ Use warm soapy water and a damp cloth if necessary.
- ▶ The evaporator fins can be rinsed off using a watering can fitted with a rose/spray head if necessary.

- ▶ Cut or remove vegetation/foliage surrounding the outdoor unit to at least the specified clearances around the unit. (Fig. 19, Table 6, page 23)
- ▶ Switch the external unit back on as soon as possible, and only if safe to do so.
- ▶ Check the refrigerant pipe insulation for damage and repair if necessary.

 **NOTICE:**

- ▶ If the power to the external unit has been off for a period of time greater than 5 minutes, the initial power up period of 12 hours (Chapter 6.1.1, Page 32) must be followed before a heat demand is requested. This is to ensure that the compressor is warmed up sufficiently to avoid any liquid refrigerant from entering the compressor. This is particularly important during colder periods. If this 12 hour time period cannot be met damage to the outdoor unit may result.

### 9.5.4 COMPLETING INSPECTION AND MAINTENANCE

- ▶ Install casing parts.
- ▶ Complete and sign the inspection and maintenance report in this manual (→ Chapter 9.6).

**9.5.5 OVERVIEW OF DIP SWITCHES IN THE EXTERNAL UNIT**


The table offers an overview of the DIP switches on the PCB of the external unit that are relevant for the hybrid system. These DIP switches are correctly set at the factory. Their setting does not need to be changed by customers.

Type	Name	No.	Function	Switch position		Changeover timing
				ON	OFF	
DIP switch	SW1	1	Forced defrost operation <sup>1)</sup>	Start	Normal	With the compressor operating in heating mode
		2	Cancelling fault displays	Delete	Normal	Anytime
DIP switch	SW5	1	No function	—	—	—
		2	Automatic restart following power failure	Starts automatically	Does not start automatically	Anytime
		3–5	No function	—	—	—
		6	Model selection (together with SW6)	Always leave switched on. (→ SW5-6)	—	—
DIP switch	SW7 <sup>2)</sup>	1	Model selection <sup>3)</sup>	Demand function	Low-noise function	Anytime
		2	No function	—	—	—
		3	Max. operating frequency in heating mode	Max. operating frequency (heating) x 0.8	Normal	Anytime
		4	Max. operating frequency in cooling mode	Max. operating frequency (cooling) x 0.8	Normal	Anytime
		5	Step control	16 A	25 A	When power supply is switched on
		6	Defrost function	For high relative humidity	Normal	Anytime
DIP switch	SW8	1	No function	—	—	—
		2	No function	—	—	—
		3	Response to fault display E8 "communication fault between hybrid manager and outdoor unit"	Fault indication E8 "communication fault between hybrid manager and outdoor unit" is ignored. The controller waits until both devices are turned on and the communication can be established	Failure E8 "communication fault between hybrid manager and outdoor unit" is displayed on the outdoor unit. Reset the fault message is possible by switching off and on the outdoor unit.	—
DIP switch	SW9	1	No function	—	—	—
		2	Function switch	Applicable	Normal	Anytime
		3–4	No function	—	—	—
DIP switch	SW6	1–5	Model selection	—	Normal	—
	SW5	6	Model selection	Normal	—	—
		7–8	Model selection	—	Normal	—
Rotary selector	SWP		Pumping back	Start	Normal	Only when external unit unit is switched off

Table 24 Assignment of DIP switches in the external unit

1) Manual start of defrost mode—Forced defrost mode for maintenance and test mode

2) Reduce operating frequency. In standard mode, DIP switches SW7-3to SW7-6 must not be changed; they only serve maintenance and test purposes. Incorrect functions and system failure can be the result of incorrect settings.

3) DIP switches SW7-1and SW7-2 can be used to set the staged switching. These switch settings are only effective during stage switching.



For DIP switch positions see Fig. 80

## 9.6 INSPECTION AND MAINTENANCE REPORTS

The inspection and maintenance reports are also designed as templates and may be photocopied.

► Sign and date the completed inspection work.

### GENERAL INFORMATION

System data	
Customer	
Installation location	

Table 25 Inspection and service reports - general details

Action	Confirmation / values
General condition of appliances checked	<input type="checkbox"/> Yes
Filter in the hybrid manager cleaned	<input type="checkbox"/> Yes
Air intake of the external unit cleaned	<input type="checkbox"/> Yes
Visual inspection and function tests carried out on the system	<input type="checkbox"/> Yes
Refrigerant and water pipes checked for the following: <ul style="list-style-type: none"> <li>• Tightness</li> <li>• Corrosion</li> <li>• Signs of ageing</li> <li>• Insulation and external damage.</li> </ul>	<input type="checkbox"/> Yes
Hybrid manager checked for the following: <ul style="list-style-type: none"> <li>• External damage and blockages</li> <li>• Flow switch function</li> <li>• Temperature sensor fittings and function</li> <li>• Correct adjustment of the hybrid control module.</li> <li>• Correct adjustment of FW200 programmable controller</li> </ul>	<input type="checkbox"/> Yes
External unit checked for the following: <ul style="list-style-type: none"> <li>• External damage and blockages</li> <li>• Cable insulation</li> <li>• Fittings of external unit</li> <li>• Correct installation of ribbon heater (option)</li> <li>• Secure fixing of the external unit on its foundations</li> <li>• Excessive oscillations or vibrations emanating from the external unit or pipe work</li> <li>• External damage on the external unit including evaporator, fan and casing.</li> </ul>	<input type="checkbox"/> Yes
Outdoor temperature sensor inspected for damage	<input type="checkbox"/> Yes
Correct adjustment of the by-pass valve	<input type="checkbox"/> Yes
Final checks of the inspection tasks carried out	<input type="checkbox"/> Yes
Casing parts installed	<input type="checkbox"/> Yes
Customer instructed and given technical documentation	<input type="checkbox"/> Yes
Correct commissioning by the installing contractor	Signature: _____
Signature of customer	Signature: _____

Table 26 Inspection and maintenance report

## 10 FAULTS

### 10.1 FAULTS THAT ARE NOT DISPLAYED

#### 10.1.1 GENERAL FAULTS

Appliance faults	Remedy
Flow noises	<ul style="list-style-type: none"> <li>▶ Set the pump rate or pump parameter field correctly and match it to the maximum output.</li> <li>▶ Vent the hybrid manager (→ chapter 6.2.11, page 38).</li> </ul>
Heat-up takes too long	<ul style="list-style-type: none"> <li>▶ Set the pump rate or pump parameter field correctly and match it to the maximum output.</li> </ul>

Table 27 Faults that are not shown on the display

#### 10.1.2 EXTERNAL UNIT FAULTS – FREQUENTLY ASKED QUESTIONS

FAQ	Steps to be taken
The external unit does not work at all.	<p>External unit cannot be returned into operation after an idle period.</p> <p>Wait at least 3 minutes before trying to restart. The external unit is protected by an automatic safety device. For 3 minutes after the compressor stops it cannot be restarted.</p>
The external unit develops too much noise.	Noise like escaping gas can be heard. This is not a fault. This noise can be heard when the refrigerant enters the system.
	A cracking sound can be heard. This is not a fault. This noise can be heard when the components in the external unit contract or expand as a result of temperature changes.
	A humming sound can be heard. This is not a fault. This noise can be heard when the external unit starts.
	A ticking noise can be heard. This is not a fault. This noise can be heard when the fan regulates the air volume to achieve the optimum operating mode.
	Noise like water can be heard. This is not a fault. This noise can be heard when the refrigerant flows into the external unit.
Water or humidity escapes from the external unit.	It is quite normal that condensate forms at certain parts. The condensate should be caught and drained off by a condensate drain or condensate pan.

Table 28 FAQ

## 10.2 DISPLAYED FAULTS

**DANGER:** Danger to life through electric shock!

- ▶ Prior to working on the electrical section, isolate the power supply (230 V AC) (fuse for the external unit, hybrid manager and heat source) and secure against unintentional reconnection.

**WARNING:** Risk of injury and damage through incorrect troubleshooting.

- ▶ Have troubleshooting carried out only by a competent person.
- ▶ Permit only qualified refrigeration engineers (F gas qualification), whose company holds a valid F gas certificate) to work on the refrigerant circuit.

External unit faults are signalled by LEDs on the PCB in the external unit Fig. 64, page 60.

Hybrid manager faults are displayed on the hybrid control module Fig. 61, page 56 and Fig. 63, page 59.

Hybrid system faults are displayed on the FW200 programming unit Fig 62, page 57.

- ▶ Identify the fault and have it rectified.
- ▶ Hold down the Back button on the hybrid control module for 5 seconds to restart the hybrid control module.

## OVERVIEW OF INTERNAL HYBRID FAULT INDICATORS LOCATIONS




Fig. 60 Overview internal hybrid components fault indicators locations

- [1] Error indicator (hybrid manager)
- [2] Display (hybrid manager)
- [3] FW200 display
- [4] Error indicator (hybrid manager)

### 10.2.1 FAULT DISPLAYS ON THE HYBRID CONTROL MODULE

Error states are indicated as operating codes by the hybrid control module.

- ▶ Display the current error code with Back button [7].  
The current operating code is displayed on the right hand side of the large display [6] (Fig. 61, page 56).



For an explanation of error codes, see table 35, from page 59.




Fig. 61 Display on the external and internal hybrid control module

Position	Symbol	Explanation
1		ON/OFF (hybrid control module)
2		Communication with the programming unit
3		Fault
4		Demand to the air to water heat pump
5		Boiler communication and boiler demand
6	—	Display
7	—	Back button
8	—	Rotary selector
9	—	Service key

Table 29 Key to Fig. 61

Indication of operating states by LED signals on the hybrid control module:

Status	LED1	LED2	LED3	LED4	LED5
Pump pre-run	○	○	●	●	●
Preheating (only air to water heat pump)	○	○	●	○	●
Operation (heat source and air to water heat pump)	○	○	●	○	○
Only air to water heat pump operation	○	○	●	○	●
Fault air to water heat pump	○	○	○	⚡	○
Fault, communication with the heat source	○	○	○	○	⚡
Boiler only mode	○	○	●	●	○
Heat source fault	○	○	○	○	⚡
Fault, communication with the programming unit	○	●	m	●	⚡

Table 30 Operating indicators on the hybrid control module  
(○ = LED illuminates, ● = LED does not illuminate, ⚡ = LED flashes)

**10.2.2 CHECK TEMPERATURE SENSOR OF HYBRID MANAGER**

T (°C)	R (Ω)
-30	83190
-20	45623
-10	26005
0	15346
10	9353

Table 31 Heating water temperature sensor

T (°C)	R (Ω)
20	5870
30	3787
40	2504
50	1693
60	1169

T (°C)	R (Ω)
70	823.4
80	591.3
90	431.3
100	319.6
—	—

T (°C)	R (Ω)
-20	39080
-10	23850
0	15000
10	9699
20	6431

Table 32 Refrigerant temperature sensor

T (°C)	R (Ω)
30	4364
40	3024
50	2138
60	1538
70	1126

T (°C)	R (Ω)
80	836.9
90	631.2
100	482.5
110	373.5
120	292.5

**10.2.3 FAULTS OF THE FW200 PROGRAMMING UNIT**

Operating and fault indications of the hybrid manager are displayed on the FW200 programming unit and on the hybrid manager control module.

The following information given in the service instructions of the FW200 programming unit is prerequisite.

- Principles of operation
- Troubleshooting

**INDICATORS ON THE HYBRID SYSTEM**

Indicators on the hybrid manager are displayed exclusively on the internal display of the hybrid control module.

LED fault	Fault No. 1)	Cause	Remedy (by contractor)
ON	5H	Relay test was activated	–
OFF		Heating and DHW mode in parallel	Hybrid system runs in heating and DHW mode simultaneously (parallel)
OFF		Pump pre-run phase in internal unit	–
OFF		Heat pump pre-heat phase	–
OFF		Heat pump in operation	–
OFF		Hybrid manager pump: post-run phase	–
OFF		Heat pump in defrost mode	–
OFF		Only EMS heat appliance in operation	–
OFF		Heat pump blocked: more than 4 starts per hour	–
OFF		Differential temperature outside the permissible range	Indicator for low system flow rate. Check filter for blockages
OFF		Heat pump operates with the boiler blocked	–
OFF		Heat pump in service mode	The heat pump is running in service mode (100% heating output) Switch over to normal mode on completion of service work. Service mode terminates automatically after 15 minutes

Table 33 Hybrid manager indicators (internal unit)

1) This fault number is displayed on the hybrid control module.

**10.2.4 FAULT DISPLAY ON THE FW 200 WEATHER-COMPENSATED CONTROLLER AT USER LEVEL**

Faults are displayed directly at user level (→ Fig. 62).

If the heat pump or the boiler is the cause of the fault, this is shown on the controller display with a corresponding message. The fault number displayed will contain at least one letter, e.g. **Fault d1** or **Fault CC** (→ Tab. 34).

If the cause of the fault (the heat pump or the boiler) cannot be identified directly from the information in the fault display:

- ▶ Check the display on the boiler:
  - If the boiler is displaying a fault (→ technical documentation for the boiler), the heat pump is not faulty.)
  - If the boiler is not displaying a fault (→ technical documentation for the FW200), before proceeding to check the heat pump.)

See the technical documentation for the FW 200 weather-compensated controller or the relevant technical documentation for more detailed information about faults caused by other system components.




Fig. 62 Fault display

- [1] Fault number
- [2] BUS device that detected the fault and reported it to all controllers
- [3] Description of fault
- [4] Code or additional information about fault



The faults are shown in descending order based on severity.  
If a fault has several causes, the next lower-priority fault is shown after troubleshooting. Tab. 34 lists the faults sorted by fault no. and code.

**FAULTS**

LED fault	Fault No. 1)	Status <sup>2)</sup>	FW 200	Steps	
			Description	Cause	Remedy (by contractor)
ON	A8	B	No communication with EMS heat appliance	Communication cannot be established between the hybrid control module (internal unit) and the boiler	Check the EMS connection between the hybrid control module (internal unit) and the boiler.
				Check the contacts, cables and connections between the hybrid control module and the boiler.	Replace damaged cables and contacts, replace the appliance PCB if necessary.
ON	A8	B	No communication with system controller	Check the contacts, cables and connections between the hybrid control module and the system controller	Repair or replace the bus cable
				Check the system controller	Replace the system controller if necessary
ON	CC	B	Outside temperature sensor faulty	Use the voltage and pressure drop values to check the sensor	If the sensor is faulty, replace it
				Check the sensor connection	Reconnect the sensor in the correct way
ON	d1	L	Return temp. sensor contact faulty	Temperature sensor short circuit - Condenser inlet	Check and possibly replace contacts, wiring or temperature sensor
ON	d1	L	Return temp. sensor contact faulty	Temperature sensor open circuit - Condenser inlet	Check and possibly replace contacts, wiring or temperature sensor
OFF		B	Flow or return temperature outside the permissible range	Hybrid manager flow or return temperature outside the permissible range	Initially the boiler heats the water before the heat pump starts.
ON	E2	L	Flow temperature sensor faulty	Temperature sensor short circuit - Condenser outlet	Check and possibly replace contacts, wiring or temperature sensor
ON	E2	L	Flow temperature sensor faulty	Temperature sensor open circuit - Condenser outlet	Check and possibly replace contacts, wiring or temperature sensor
ON	EF	L	System fault appliance PCB / basic controller	Check contact between the appliance PCB and the mounting base along with the base controller and the base plate, and check all other plug-in connections	Rectify contact problem, replace appliance PCB or boiler identification module if necessary
				Hybrid system: Component fault in hybrid control module	Check the hybrid control module and replace if necessary
ON	HP	L	External unit / water flow rate fault	Fault affecting the heat pump / water flow interrupted	Check LED signals on hybrid control module.
					Check throughput of heat pump.
					Check filter and replace if necessary.
					Check and possibly replace the flow switch.
					Check system
ON	HP	L	Heat pump flow switch fault during self-test	Check flow switch	Replace flow switch if necessary
On	EF	L	(Display blank)	EEPROM error in the hybrid control module	Check and possibly replace hybrid control module

Table 34 Hybrid manager (internal unit) and weather-compensated controller fault displays

1) This fault number is displayed on the hybrid control module and on the FW200.

2) Status: locking (L); blocking (B)

### 10.2.5 FAULT DISPLAY ON THE REAR OF THE HYBRID MANAGER

Indication of operating states by LED signals at the interface to the external unit:

Status	LED2	LED3
Standard operation	○	⚡
Fault, communication with the hybrid manager	○	●

Table 35 Operating code at the interface to the external unit  
(○ = LED illuminates, ● = LED does not illuminate, ⚡ = LED flashes)




Fig. 63 LED Position at the interface to the external unit

- [1] LED3
- [2] LED2


**10.2.6 EXTERNAL UNIT FAULTS**

 **DANGER:** Risk to life through accumulated charges. With the power supply switched off, electronic components may still hold an electric charge that is maintained after switching off and isolation from the power supply. Contact with such components can result in severe or fatal injuries.

► Once the green LED on the PCB of the external unit has extinguished, wait at least a further 10 minutes.

 External unit faults are signalled by LED1 (green) and LED2 (red) on the PCB in the external unit.

**EXTERNAL UNIT LED DISPLAY**



6720803687-08.1Wo

Fig. 64 LED position at the external unit

LED	Colour	Description
2	Red	Voltage
1	Green	Requirement

Table 36 LED colour assignment

When a fault display is shown, observe the following:

- When a fault occurs, the fault code will be signalled by two LEDs flashing on the external unit.
- The fault code will be indicated (P1, E6 etc.) if troubleshooting is carried out using the service tool.

► For description, cause and remedy of a fault, see the following table.

Operating state	Indication on the PCB of the external unit		Service tool (7-716-161-051)	
	LED green	LED red	Code	Display indication
If the external unit is switched on	○	○	- <---> -	Alternately flashing display
If the external unit stops	○	●	00, ...	Operating mode
If the compressor in the external unit heats up	○	●	08, ...	
If the external unit operates	○	○	C5, H7, ...	

Table 37 LED display of the external unit (○ = LED illuminates, ● = LED does not illuminate)

 The cause, remedy or checking of the codes in table 38 are explained in detail in the following table 39. Use the service tool (7-716-161-051) for a more detailed diagnosis.

Indication on the PCB of the external unit		Description	Code	
LED (green) flashes	LED (red) flashes			
1 x	2 x	High pressure switch 63H	F5	
2 x	1 x	Control cable wiring fault between internal and external unit – phases reversed, no contact	Eb	
		Time limit exceeded for start of operation.	EC	
	2 x	Signalling error between the internal and external units (reception error) recognised by the internal unit.	E6	
		Signalling error between the internal and external units (transmission error) recognised by the internal unit.	E7	
		Signalling error between the internal and external units (reception error) recognised by the external unit.	–	
			Signalling error between the internal and external units (transmission error) recognised by the external unit.	–
	4 x	Unknown fault.	EF	
5 x	Communication error / serial operating signal.	Ed		
	No function.	A0-A8		
3 x	1 x	Excessively high temperature at the hot gas temperature sensor TH4 and at the compressor temperature sensor TH32.	U2	
		Superheating not possible through hot gas temperature being too low.	U7	
	2 x	High pressure too high (63H has responded).	U1	
	3 x	Speed fault at the fan motor.	U8	
		Overheating protection (overload protection, fan motor fault).	Ud	
	4 x	Safety device to protect against compressor overcurrent: compressor blocked.	UF	
		Current sensor fault	UH	
		Compressor overcurrent – safety device has responded	UP	
		Power module in inverter circuit faulty	U6	
	5 x	Open / short circuit on hot gas temperature sensor TH4 or compressor temperature sensor TH32	U3	
Open / short circuit on external unit temperature sensors (TH3, TH32, TH33, TH6, TH7 and TH8)		U4		
6 x	Temperature fault on inverter radiator panel	U5		
7 x	Inverter over or undercurrent and fault in the serial PCB communication	U9		

Table 38 LED fault display on external unit

**FAULTS**

Code	Description	Cause	Possible solution / check
No indication	—	No supply voltage applied to terminal block TB1. • The mains isolator upstream is switched off • Poor connection/contacts or terminal loose • Open phase (L, L1 or N).	▶ Check mains isolator ▶ Check and correct connection, wiring, phases and contacts at TB1.
		No voltage applied to power supply input on power circuit board. • Poor connection/contacts or terminal loose • Power circuit board open phase • Disconnected plug (R or S).	▶ Check and correct connection, wiring, phases and contacts at TB1. ▶ Check connection, wiring, phases and contacts on the plugs on the power circuit board and correct if required.
		The PCB receives no power. • Poor connection/contacts or terminal loose at the CNDC plug, or plug pulled.	▶ Check and repair contact at the CNDC plug on the PCB. ▶ Check and repair contacts LD1 and LD2 at the power circuit board and repair if required.
		Poor connection/contacts or terminal loose at the DCL or ACL transformer.	▶ Check and repair contacts at the DCL transformer. ▶ "LO" and "NO" on the interference suppressor board, R and S on the power circuit board.
		Power circuit board faulty.	▶ Replace faulty power circuit board.
		PCB at the external unit faulty.	▶ Replace faulty PCB if the steps above have not removed the problems.
		Time limit exceeded for start of operation	▶ Check whether the electromagnetic compatibility of terminals, power supply or the PCB is being compromised. ▶ Switch the power supply off and on to restart the system.
F5	<b>High pressure switch 63H</b> If no contact is signalled by high pressure switch 63H for more than 3 minutes after applying the supply voltage, fault display "F5" is shown.	Poor connection/contacts or terminal loose at the 63H plug on the PCB of the external unit or plug pulled.	▶ Check and repair contact at the 63H plug on the PCB.
		Poor connection/contacts or terminal loose on the 63H.	▶ Check and repair contacts and cable on the 63H.
		63L tripped by faulty components.	▶ Test electrical components. ▶ Replace faulty components.
		Circuit board faulty.	▶ Replace faulty PCB.
EA	<b>Control cables between internal and external unit faulty – too many internal units connected</b> A test circuit recognises the number of connected internal units automatically. Fault message "EA" will be displayed if a control cable has a fault for longer than 4 minutes after a power supply has gone 'live'.	Poor connection/contacts or terminal loose at the control cable connections or wiring error.	▶ Check and repair contacts, cables and control cable connections for all appliances.
		Control cables incorrectly sized.	▶ Check and correct control cable cross-section and cable lengths: max. length 30 m. ▶ Check and correct polarity of control cables S1, S2 and S3.
		Transmitter/receiver circuit on external unit faulty.	▶ Switch supply voltage off and on and check if the fault occurs again. ▶ Replace PCBs of the internal or external units concerned if the fault recurs. Check the control cables.
		Transmitter/receiver circuit on internal unit faulty.	
		Noise in the control cables.	▶ Check the control cables and eliminate cause of noise.
Eb	<b>Control cable wiring fault between internal and external unit – phases reversed, no contact</b> A test circuit sets the number of connected internal units automatically. If the control cables are faulty for more than 4 minutes after connecting the power supply, the fault display is "Eb" is shown.	Poor or detached contacts at the control cable connections or wiring faults.	▶ Check and repair contacts, cables and control cable connections for all appliances.
		Control cables incorrectly sized.	▶ Check and correct control cable cross-section and cable lengths: max. length 30 m. ▶ Check and correct polarity of control cables S1, S2 and S3.
		Transmitter/receiver circuit on external unit faulty.	▶ Switch supply voltage off and on and check if the fault occurs again. ▶ Replace PCBs of the internal or external units concerned if the fault recurs. ▶ Check the control cables.
		Transmitter/receiver circuit on internal unit faulty.	
		Noise in the control cables.	▶ Check the control cables and eliminate cause of noise.
		Power circuit board on external unit faulty.	▶ Switch supply voltage off and on and check if the fault occurs again. ▶ Replace PCBs of the internal or external units concerned if the fault recurs. Check the control cables.

*Table 39 Fault indications, external unit*

Code	Description	Cause	Possible solution / check
EC	<b>Time limit exceeded for start of operation</b> The system has not initialised correctly after 4 minutes have elapsed since start of operation. The fault display "EC" is shown.	Poor connection/contacts or terminal loose at the control cable connections or wiring error.	▶ Check and repair contacts, cables and control cable connections for all appliances.
		Control cables incorrectly sized.	▶ Check and correct control cable cross-section and cable lengths: max. length 30 m (internal unit - external unit) or max. 30 m (internal unit - internal unit). ▶ Check and correct polarity of control cables S1, S2 and S3.
		Noise in the control cables.	▶ Check the control cables and eliminate cause of noise.
U1	<b>High pressure too high (63H tripped)</b> The high pressure switch 63H tripped because the high pressure rose above 4.14 MPa during compressor operation.	Faulty ball valve (not completely open).	▶ Check if all ball valves are completely open.
		Clogged or broken refrigerant line.	▶ Check pipe work and eliminate fault.
		Blocked fan motor on external unit.	▶ Check external unit and replace or repair faulty components.
		Faulty functioning of external unit fan motor.	
		Air short circuit on external unit.	
		Contamination on the external unit's heat exchanger.	
		Reduced air flow rate due to faulty temperature measurement on outside temperature sensor (measurement too low).	▶ Check outside temperature sensor including connections and cable, and replace if required.
		Faulty contact on plug 63H on the PCB of the external unit.	▶ Switch the supply voltage off and on again. ▶ Check whether fault code "F5" is then displayed. If yes, see "Possible solution / check" for "F5".
		Faulty connection of 63H.	
		Faulty external unit PCB	
Faulty linear expansion valve (LEV).	▶ Check linear expansion valve (LEV).		
Faulty fan operation.	▶ Replace faulty external unit PCB.		

Table 39 Fault indications, external unit

**FAULTS**

Code	Description	Cause	Possible solution / check
U2	<b>(1) Hot gas temperature too high</b> On the hot gas temperature sensor TH4, over 125 °C is measured or over 110 °C is measured for a period of 5 minutes. In defrost mode, on TH5 over 40 °C and on the hot gas temperature sensor TH4 over 110 °C is measured.	Temperature increase in compressor due to insufficient refrigerant.	<ul style="list-style-type: none"> <li>▶ Check inlet overheating.</li> <li>▶ Check for leaks on the refrigerant lines and seal, if required, then refill the system.</li> </ul>
		Faulty ball valve (not completely open).	▶ Check if all ball valves are completely open.
		Faulty temperature sensor TH4, TH5.	▶ Switch the supply voltage off and on again.
		Faulty external unit PCB	▶ Check if fault code "U3" is shown. If yes, see "Possible solution / check" for "U3".
		Faulty linear expansion valve (LEV).	▶ Check linear expansion valve (LEV).
U2	<b>(2) Insufficient refrigerant</b> Faulty if hot gas overheating rises in cooling mode TH4 to TH5 or in heating mode TH4-TH6 as follows. All conditions must be met for 10 minutes (at least for 6 minutes after compressor start). Conditions 1: <ul style="list-style-type: none"> <li>• Compressor is running in heating mode</li> <li>• Hot gas overheating is 70 °C or higher</li> <li>• TH6 &gt; TH7 - 5K</li> <li>• TH5 &lt; 35 °C.</li> </ul> Conditions 2: <ul style="list-style-type: none"> <li>• Compressor is running</li> <li>• Hot gas overheating is 80 °C or higher in cooling mode</li> <li>• Hot gas overheating is 90 °C or higher in heating mode</li> <li>• Condensation temperature TH6 &lt; -40 °C in cooling mode.</li> </ul>	Temperature increase in compressor due to insufficient refrigerant.	<ul style="list-style-type: none"> <li>▶ Check inlet overheating.</li> <li>▶ Check for leaks on the refrigerant lines and seal, if required, then refill the system.</li> </ul>
		Faulty ball valve (not completely open).	▶ Check if all ball valves are completely open.
		Faulty temperature sensor TH4, TH5, TH6	▶ Switch the supply voltage off and on again.
		Faulty external unit PCB	▶ Check if fault code "U3" is shown. If yes, see "Possible solution / check" for "U3".
		Faulty linear expansion valve (LEV).	▶ Check linear expansion valve (LEV).

*Table 39 Fault indications, external unit*

Code	Description	Cause	Possible solution / check
U2	<b>(3) Compressor temperature too high</b> Faulty if temperature sensor TH32 exceeds 125 °C or 110 °C for 5 minutes.	See U2 (2), but replace temperature sensors TH4, 5 and 6 with temperature sensor TH32	See U2 (2)
U3	<b>Open / short circuit on hot gas temperature sensor TH4 or compressor temperature sensor TH32</b> If the hot gas temperature sensor TH4 cannot capture any temperature ( $\leq 3$ °C) or indicates an infinite resistance ( $> 217$ °C) whilst the compressor is working, fault display "U3" will be shown. This function is not available in the following situations: • In the first 5 to 10 minutes after the compressor starts • At the end of the defrost mode • When defrost mode is running	Poor connection/contacts or terminal loose at the cables and plugs on the PCB.	▶ Check and repair plug and contacts of the temperature sensor of the PCB. ▶ Check temperature sensor connecting leads for cable breaks or the like.
		Faulty temperature sensor.	▶ Check temperature sensors TH4 and TH32 with service tool (7-716-161-051).
		Faulty external unit PCB	▶ Replace faulty external unit PCB.
U4	<b>Open / short circuit on external unit temperature sensors (TH3, TH32, TH33, TH6, TH7 and TH8)</b> If a temperature sensor does not measure any resistance ( $0 \Omega$ ) or measures an infinitely large resistance ( $8 \Omega$ ) when the compressor is running, fault display "U4" is shown.	Poor or loose contacts at the cables and plugs on the PCB.	▶ Check and repair plug and contacts of the temperature sensor of the PCB. ▶ Check temperature sensor connecting leads for cable breaks or the like.
		Faulty temperature sensor.	▶ Check temperature sensors TH32 with service tool (7-716-161-051).
		Faulty external unit PCB	▶ Replace faulty external unit PCB.
U5	<b>Temperature fault on inverter radiator panel</b> If the temperature at TH8 (heat deflector) reaches or exceeds the specified value, fault display "U5" will be shown. • RP35 84 °C.	Blocked fan motor.	▶ Check fan motor.
		Fan motor fault.	
		Ventilation and extract air apertures dirty or blocked.	▶ Check and clean ventilation and extract air apertures.
		Rising outside temperature.	▶ Check if causes other than the weather are responsible for the temperature increase. Upper temperature limit 46 °C. Switch the supply voltage off and on again. ▶ Within 30 minutes, check if fault display "U5" is shown again. If fault display "U4" is shown instead of "U5", follow the descriptions provided for "U4".
		Faulty temperature sensor.	▶ Check resistance of temperature sensor TH8 (should be between 39 and 105 k $\Omega$ ). ▶ Replace faulty temperature sensor.
		Faulty input circuits (supply voltage) on external unit power circuit board.	▶ Replace faulty external unit power circuit board.
U6	<b>Power module in inverter circuit faulty</b> If overcurrent is detected in the inverter circuit ("UF" or "UP" is shown), the inverter circuit is faulty and fault display "U6" is shown.	Faulty ball valve (not completely open).	▶ Check and completely open all ball valves.
		Reduced supply voltage.	▶ Check supply voltage (mains side).
		Poor connection/contacts or terminal loose on compressor supply cable or phases swapped.	▶ Check and correct compressor wiring.
		Faulty power circuit board.	▶ Replace faulty external unit power circuit board.
		Faulty compressor.	▶ Replace external unit.

Table 39 Fault indications, external unit

**FAULTS**

Code	Description	Cause	Possible solution / check
U7	<b>Overheating faulty due to insufficient hot gas temperature</b> Fault display "U7" is shown when superheating of -15 °C lasted longer than 3 minutes, with the LEV almost closed (lowest pulse rate) and 10 minutes have passed since the compressor started.	Poor connection/contacts or terminal loose at the cables and plugs of hot gas temperature sensor TH4 on the PCB.	► Check and repair contacts, cables and connections for temperature sensor TH4.
		Faulty fixing of hot gas temperature sensor TH4.	► Secure temperature sensor TH4 correctly.
		Poor connection/contacts or terminal loose at the cables and plugs on the LEV drive.	► Check connections, contacts and terminals on the LEV drive and repair or replace if required.
		Poor or loose contacts at the LEV cables on the PCB.	► Check and repair contacts, cables and connections of the LEV cables.
		Faulty linear expansion valve (LEV).	► Check linear expansion valve (LEV) and replace if required.
U8	<b>Fan motor speed fault</b> The speed on the fan motor is determined to be faulty if <ul style="list-style-type: none"> <li>• a maximum of only 100 rpm is measured for a period of 15 seconds at an outside temperature of 20 °C or above</li> <li>• less than 50 rpm or more than 1500 rpm is measured for a period of one minute</li> </ul>	Fan motor faulty.	► Check fan motor and replace faulty motor.
		Circuit board faulty.	► Check PCB and replace, if faulty.
U9	<b>Inverter over or undercurrent and fault in the serial PCB communication</b> <ul style="list-style-type: none"> <li>• Sudden drop in bus voltage below 200 V</li> <li>• Increase in bus voltage above 420 V</li> <li>• External unit power consumption drops to only 0.1 A at an operating frequency of 40 Hz or a compressor current of 6.0 A.</li> </ul>	Increase in supply voltage (mains side).	► Check supply voltage on mains side.
		Wiring detached from compressor.	► Check and correct wiring on compressor and power circuit board.
		Faulty PFC module on external unit power circuit board.	► Replace PCB.
		Faulty ACT module.	► Replace ACT module.
		CNAF plug detached or disconnected.	► Check and correct fit and wiring of CNAF.
		Faulty 52C circuit on PCB.	► Replace PCB.
		CN5 plug on power circuit board detached or disconnected.	► Check and correct fit and wiring of CN5.
CN2 plug on power circuit board detached or disconnected.	► Check and correct fit and wiring of CN2.		

*Table 39 Fault indications, external unit*

Code	Description	Cause	Possible solution / check
Ud	<b>Overheating protection (overload protection, fan motor fault)</b> If the line temperature (TH3) exceeds 70 °C, fault display "Ud" is shown.	Temperature sensor TH3 faulty.	▶ Check temperature sensor, replace faulty temperature sensor.
		Circuit board faulty.	▶ Check PCB, replace if faulty.
UF	<b>Protective equipment against compressor overcurrent: compressor blocked</b> If overcurrent is measured in the DC-BUS or in the compressor 30 seconds after the compressor start, fault display "UF" is shown.	Shut-off valves closed.	▶ Open shut-off valves.
		Reduced supply voltage (mains side).	▶ Check supply voltage on mains side.
		Plug detached or disconnected, cable break, phases reversed.	▶ Check and correct wiring on compressor and power circuit board and replace faulty components.
		Compressor faulty.	▶ Replace external unit.
		Power circuit board faulty.	▶ Replace power circuit board.
UH	<b>Current sensor fault</b> Fault display "UH" is shown if the voltage sensor captures a voltage between -1.5 V and +1.5 V. This fault is ignored in test mode.	Poor connection/contacts or terminal loose on compressor supply cables.	▶ Check and correct compressor wiring.
		Faulty circuit (current sensor) on the external unit power circuit board.	▶ Replace faulty external unit power circuit board.

Table 39 Fault indications, external unit

**FAULTS**

Code	Description	Cause	Possible solution / check
UL	<b>Low pressure fault</b> Fault "UL" is shown if the following conditions are met for 3 minutes in 10 following compressor start in heating mode. <ul style="list-style-type: none"> <li>• TH7 - TH3 ≤ 4 K</li> <li>• TH5 - Room temperature ≤ 2 K.</li> </ul> This means: TH3: liquid line temperature in the external unit in °C. TH5: evaporator/condenser temperature in the internal unit in °C. TH7: outside temperature in °C.	Shut-off valves closed.	▶ Open shut-off valves.
		Insufficient refrigerant or leak.	▶ Check amount of refrigerant and additional charge. ▶ Check pipe system for leaks and eliminate any leaks. ▶ Check increased heat through superheating.
		Faulty linear expansion valve (LEV).	▶ Check linear expansion valve (LEV).
		Refrigerant circuit blocked by foreign objects or contaminated by water.	▶ Vacuum out refrigerant. ▶ Subject the refrigerant circuit to the vacuum for at least one hour to remove the water. ▶ Refill with clean refrigerant.
UP	<b>Compressor overcurrent – safety device has responded</b> If the protective equipment is tripped 30 seconds after the compressor start due to DC overcurrent, fault display "UP" is shown.	Ball valve closed in operation.	▶ Check and completely open all ball valves.
		Reduced supply voltage (mains side).	▶ Check supply voltage (mains side).
		Poor connection/contacts or terminal loose on compressor supply cables.	▶ Check and correct compressor wiring.
		Fan faulty.	▶ Check fan.
		Air short circuit on internal or external unit.	▶ Eliminate air short circuit.
		Faulty input circuit (voltage) on the external unit PCB.	▶ Replace faulty PCB.
		Faulty compressor.	▶ Check compressor and replace external unit if required.
		Inverter board faulty.	▶ Replace faulty PCB.
DIP switch settings incorrect on the external unit PCB.	▶ Check DIP switches and correct settings.		
E6	<b>Signalling error between the internal and external units (reception error)</b> The internal unit cannot receive any signals within 6 minutes from start or after 3 minutes in operation. Fault display "E6" is shown.	Poor connection/contacts or terminal loose on the control cables, cable break.	▶ Check and correct wiring for all control cables between internal and external unit.
		Faulty transmitter/receiver circuit on external unit PCB.	▶ Check whether the fault display E6 will still be issued after a restart.
		Faulty transmitter/receiver circuit on internal unit PCB.	▶ Check PCBs of the internal and external units and replace if faulty.
		Noise in the control cables.	
		Fan motor faulty.	▶ Isolate the external unit from the power supply, and undo terminal CNF 1 on the fan motor. Restart external unit. <ul style="list-style-type: none"> <li>– Replace fan motor if the fault message is no longer displayed.</li> <li>– Replace the external unit PCB if the fault message continues to be displayed.</li> </ul>
Faulty starting current limiter on the external unit PCB.	▶ Check starting current limiter and replace if required.		
E7	<b>Signalling error between the internal and external units (transmission error)</b> Fault display "E7" will be shown if it has been recognised 30 times that "1" is being received constantly, however the internal unit sends "0".	Faulty transmitter/receiver circuit on internal unit PCB.	▶ Check whether the fault display E7 will still be issued after a restart.
		Noise in the voltage system.	▶ Check PCBs of the internal and external units and replace if faulty.
		Noise in the control cables.	
E8	<b>Communication error between internal and external unit – reception error</b> If the external unit cannot receive any signals within 3 minutes, fault display "E8" is shown.	Poor connection/contacts or terminal loose on the control cables, cable break.	▶ Check and correct wiring for all control cables between internal and external unit.
		Faulty transmitter/receiver circuit on external unit.	▶ Switch the supply voltage off and on again (reset system).
		Faulty transmitter/receiver circuit on internal unit.	▶ Check if fault display "E8" is shown again after the restart.
		Noise in the control cables.	▶ Check PCBs of the internal and external units and replace if faulty.

Table 39 Fault indications, external unit

Code	Description	Cause	Possible solution / check
E9	<p><b>Communication error between internal and external unit – transmission error</b></p> <p>Fault display “E9” is shown in the following cases (on the external unit only).</p> <ul style="list-style-type: none"> <li>Failed 30 times to receive a “0” when a “1” is expected.</li> <li>The external unit cannot transmit a signal within 3 minutes because the lines are busy.</li> </ul>	Poor connection/contacts or terminal loose on the control cables, cable break.	▶ Check and correct wiring for all control cables between internal and external unit.
		Faulty transmitter/receiver circuit on external unit.	▶ Switch the supply voltage off and on again (reset system).
		Noise in the voltage system.	▶ Check if fault display “E9” is shown again after the restart.
		Noise in the control cables.	▶ Check PCBs of the internal and external units and replace if faulty.
EF	<p><b>Unknown fault</b></p> <p>An unknown fault was received and fault display “EF” is shown.</p>	Noise in the control cables between internal and external unit.	▶ Switch the supply voltage off and on again (reset system). ▶ Check if fault display “EF” is shown again after the restart. ▶ Check PCBs of the internal and external units and replace if faulty.
		The external unit is not a power inverter model.	▶ Use a power inverter external unit.
Ed	<p><b>Communication error – serial operating signal</b></p> <p>There has been a fault in the communication between the power circuit board and the PCB in the external unit.</p>	Poor connection/contacts or terminal loose at the terminal of the connection cables between the PCB and the power circuit board of the external unit (CN2). Cable break.	▶ Check wiring and plug CN2 and CN4 between the PCBs and correct if required.
		Poor connection/contacts or terminal loose at the terminal of the connection cables between the PCB and the power circuit board of the external unit (CN4). Cable break.	
		Faulty power circuit board communication circuit.	▶ Check power circuit board.
		Faulty PCB communication circuit.	▶ Check PCB.
P8	<p><b>Pipe work temperature TH</b></p> <p>Ten seconds after the compressor start, the “Hot Adjust” heat-up mode is already completed, fault display “P8” is shown if the heating temperature is out of range for at least 20 minutes.</p> <p>To identify these faults takes 27 minutes. This check is not implemented in defrost mode. The check restarts after the defrost mode has terminated. Permissible temperature range in heating mode: <math>3\text{ K} \leq \text{pipe work temperature of the internal unit (TH5)} - 18\text{ °C (TH1)}</math>.</p>	Slow increase of temperature differential between room temperature and pipe work temperature (line or heat exchanger) in the internal unit due to: <ul style="list-style-type: none"> <li>Refrigerant shortage</li> <li>Temperature sensor in the internal unit detached from its holder.</li> <li>Refrigerant circuit fault.</li> </ul>	▶ Check internal unit temperature sensor using the system monitor (external unit PCB or “PAC-SK52ST” diagnostic device). ▶ $\text{TH1} = 7\text{ K } \Omega$ (equals $18\text{ °C}$ )
		Capturing error at temperature sensor TH5.	
		Refrigerant lines reversed.	▶ Check pipe work and wiring.
		Control lines reversed.	
	4-way valve faulty.	▶ Check functioning of 4-way valve.	

Table 39 Fault indications, external unit

**10.2.7 CHECK COMPONENTS**

Component	Points and criteria to check	Illustration
Temperature sensor: • Liquid line TH3 • Hot gas TH4 • Evaporator TH6 • Fresh air TH7 • Heat deflector TH8 • Compressor shell TH32 • Outdoor pipes TH33	► Check the temperature sensor resistance (sensor temperature range from 10 °C to 30 °C).	
	TH3, TH6, TH7, TH33: • Standard: 4.3 k $\Omega$ – 9.6 k $\Omega$ • Faulty: circuit open / short circuit	
	TH4, TH32: • Standard: 160 k $\Omega$ – 410 k $\Omega$ • Faulty: circuit open / short circuit	
	TH8: • Standard: 93 k $\Omega$ – 105 k $\Omega$ • Faulty: circuit open / short circuit	
4-way valve	► Check resistance across terminals (20 °C ambient temperature). • Standard: 2350 $\pm$ 170 $\Omega$ • Faulty: circuit open / short circuit	
Compressor motor MC	► Check winding resistance across terminals (20 °C winding temperature). • U-V: 0.64 $\Omega$ • U-W: 0.64 $\Omega$ • V-W: 0.64 $\Omega$ • Faulty: circuit open / short circuit	
Linear expansion valve (LEV-A / LEV-B)	► Pull plug and check winding resistance across contacts (20 °C ambient temperature).	
	• Red-white: 46 $\Omega \pm$ 4 • Red-orange: 46 $\Omega \pm$ 4 • Brown-yellow: 46 $\Omega \pm$ 4 • Brown-blue: 46 $\Omega \pm$ 4 • Faulty: circuit open / short circuit	

Table 40 Check components

**10.2.8 DC FAN MOTORS/CHECK PCB**




Table 41 DC fan motors/check PCB

10.2.9 CHECK EXTERNAL UNIT TEMPERATURE SENSOR

Temperature sensor	Designation	Reference curve
TH3, TH33	Liquid line temperature sensor	A
TH4	Hot gas temperature sensor	C
TH6	Evaporator/temperature sensor	A
TH7	Outdoor air temperature sensor	A
TH8	Heat deflector temperature sensor	B
TH32	Compressor casing temperature sensor	C

Table 42 Temperature sensor overview




Table 43 Reference curve A

**Reference curve B**

Temperature sensor  $R_{50} = 17 \text{ k}\Omega \pm 2\%$  constant  
 $B = 4150 \text{ k}\Omega \pm 2\%$

$$R_t = 17 \exp \left\{ 4150 \left( \frac{1}{273+t} - \frac{1}{323} \right) \right\}$$

**Value range**

0 °C	180 k Ω
25 °C	50 k Ω
50 °C	17 k Ω
70 °C	8 k Ω
90 °C	4 k Ω




Table 44 Reference curve B

**Reference curve C**

Temperature sensor  $R_{120} = 7.465 \text{ k}\Omega \pm 2\%$  constant  
 $B = 4057 \text{ k}\Omega \pm 2\%$

$$R_t = 7,465 \exp \left\{ 4057 \left( \frac{1}{273+t} - \frac{1}{393} \right) \right\}$$

**Value range**

20 °C	250 k Ω
30 °C	160 k Ω
40 °C	104 k Ω
50 °C	70 k Ω
60 °C	48 k Ω
70 °C	34 k Ω
80 °C	24 k Ω
90 °C	17.5 k Ω
100 °C	13.0 k Ω
110 °C	9.8 k Ω




Table 45 Reference curve C

**10.2.10CHECK LINEAR EXPANSION VALVES (LEV)**




Fig. 65 Wiring diagram, linear expansion valves LE

- |            |                       |
|------------|-----------------------|
| [1] Red    | [6] White             |
| [2] Brown  | [7] Drive circuit     |
| [3] Blue   | [8] CNLEV plug        |
| [4] Orange | [9] External unit PCB |
| [5] Yellow |                       |

**CONTROL SIGNAL SWITCHING PATTERN**



The extent to which the linear expansion valve opens depends on the number of pulses that are supplied by the PCB drive circuit to the LEV drive.

Output (phase)	Signal pattern							
	1	2	3	4	5	6	7	8
φ1	ON	ON	OFF	OFF	OFF	OFF	OFF	ON
φ2	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
φ3	OFF	OFF	OFF	ON	ON	ON	OFF	OFF
φ4	OFF	OFF	OFF	OFF	OFF	ON	ON	ON

Table 46 Control signal switching pattern

The switching pattern of the control signals changes as follows, if the valve:

- should open: 1 → 2 → 3 → 4 → 5 → 6 → 7 → 8 → 1
- should close: 8 → 7 → 6 → 5 → 4 → 3 → 2 → 1 → 8

All outputs φ1 to φ4 will be switched off if the current valve position is to be maintained.

In the case of an error in the output signals, for example if an output is missing or signals are sent permanently, the valve drive cannot open or close evenly. Movement will be jerky and vibrations can be heard and felt.

**FUNCTION AND OPERATION**

On switching the power supply on, an opening signal of 700 pulses will be sent to ensure that the valve is in position [5]. The signal remains active for approximately 20 seconds. The LEV normally operates free of noise and vibrations. Increased noise can be heard from the valve if it is blocked or is being moved from [6] to [5].

No noise can be heard if the drive is faulty or has a wiring fault.



To ascertain whether the valve is making any noise, hold the tip of a screwdriver against the valve body and listen with your ear against the screwdriver handle.




Fig. 66 LEV function diagram

- [x] Complete closing (200 pulses)
- [1] Level of opening of the LEV (top open, bottom closed)
- [2] LEV pulses (fully open at 500 pulses)
- [3] Valve closes
- [4] Valve opens
- [5] Position 1
- [6] Position 2

## 11 REPLACE COMPONENTS

### 11.1 PUMPING REFRIGERANT BACK INTO THE EXTERNAL UNIT



**DANGER:** Risk to life due to escaping refrigerant! Escaping refrigerant can result in asphyxiation and frost bite in the case of contact at its exit point.

- ▶ When refrigerant escapes, never touch any components of the air to water heat pump and ensure adequate fresh air ventilation.
- ▶ Avoid skin or eye contact with refrigerant.
- ▶ Seek medical attention if you get refrigerant on your skin or in your eyes.



**NOTICE:** Damage from wet conditions! Ingress of rain, humidity or dust can damage the PCB inside the external unit.

- ▶ Never work on the external unit when it is raining.
- ▶ Following work on the terminal strip check that the service cover sits firmly.

#### GENERAL NOTES

In this system, only R410A refrigerant is used.

- ▶ Only qualified and authorised refrigeration engineers may work on to the refrigerant system.
- ▶ During installation work, use the tools and components specifically designed for handling R410A refrigerant.
- ▶ Ensure the tightness of the refrigerant system. Escaping refrigerant coming into contact with a naked flame will produce poisonous gases.
- ▶ Never release refrigerant to the atmosphere.

#### PREPARING THE HYBRID MANAGER

The refrigerant must be pumped back into the refrigerant collector in the external unit, when working on the refrigerant circuit and also when replacing the external unit or the hybrid manager.

- ▶ Ensure there are no current or pending heat demands and the system has been idle for at least 5 minutes.
- ▶ Disconnect the power supply of the external unit (circuit breaker) and the hybrid manager (switch off).
- ▶ Undo screws at the top and bottom of the appliance.
- ▶ Remove casing.
- ▶ Undo fixing screw on the left [1] of the hybrid control module.
- ▶ Push out the spring plate [2] and tilt the hybrid control module forward.




Fig. 67 Tilting the control unit forward

- [1] Fixing screw
- [2] Spring plate

- ▶ Undo two screws and remove the small cover for the internal connections at the back.




Fig. 68 Removing the small cover

- ▶ Undo two screws and remove the larger cover at the back.




Fig. 69 Removing the cover

- ▶ The DIP switches are now accessible.
- ▶ Put DIP switches in "Pump back refrigerant" position.




Fig. 70 DIP switches in "Pump back refrigerant" position

**PREPARING THE EXTERNAL UNIT**



Only start refrigerant collection after the external unit has not operated for a period of 5 minutes or longer.

- ▶ Connect a pressure gauge to the service port [3] (Fig. 32, page 29) to check the pressure in the refrigerant system whilst pumping the refrigerant back to the external unit.
- ▶ Remove caps from the shut-off valve on the pipe work for liquid and gaseous refrigerant (→ Fig. 32, page 29).
- ▶ Turn Allen screw clockwise to close the shut-off valve on the pipe work for liquid refrigerant.
- ▶ Remove the three top cover fixing screws, and lift the top cover away.




Fig. 71 Lifting the external unit top cover away

**PUMPING REFRIGERANT BACK INTO THE EXTERNAL UNIT**



**WARNING:** Risk of injury due to moving parts!  
When the “SWP” button is pressed the fan will immediately start to run.

- ▶ Ensure no loose clothing or tools can fall into or get caught in the fan.
- ▶ Keep hands clear.

- ▶ Switch on the power supply to the external unit and the hybrid manager.



**CAUTION:** Risk of injury from poisonous gases!  
Escaping refrigerant coming into contact with a naked flame will produce poisonous gases.

- ▶ Never release refrigerant to the atmosphere.

- ▶ Press “SWP” on the external unit PCB.  
The fan and compressor will both start running and begin pumping refrigerant back into the external unit.  
LED1 and LED2 on the external unit PCB light up.  
The refrigerant is pumped back to the external unit via the pipe work for gaseous refrigerant.

As soon as the unit automatically stops (about 2 to 3 minutes after start):

- ▶ Quickly close the gas shut-off valve.  
This prevents refrigerant from flowing back into the refrigerant circuit.

To ensure that the refrigerant has been completely pumped down:

- ▶ Check the pressure in the refrigerant circuit at the pressure gauge on the service port.  
The pressure must be 0 Pa (0 mbar (a)).

If the external unit is switched off before pump down is complete, or if the refrigerant was not successfully pumped back into the external unit (compressor does not run for 2 to 3 minutes):

- ▶ Completely open shut-off valve on the pipe work for gaseous refrigerant.
- ▶ Wait 3 minutes.
- ▶ Pump back the refrigerant again.

If the external unit stopped normally:

- ▶ Disconnect the power supply of the external unit (circuit breaker) and the hybrid manager (switch off).
- ▶ Replace the top cover on the external unit and secure with the four screws.
- ▶ Return the DIP switches at the interface to the external unit in the hybrid manager into their standard setting.

SW 1		SW 2		SW 3							
1	X			1	X			1	X		
2	X			2		X		2	X		
3			X	3	X			3	X		
4	X			4	X			4	X		
5	X			5	X			5	X		
6	X			6		X		6	X		
7	X			7	X			7	X		
8	X			8	X			8	X		
	OFF	ON			OFF	ON			OFF	ON	

6 720 646 970-45.2ITL

Fig. 72 DIP switches in normal position

- ▶ Fit the covers onto the control unit enclosure and control module, flip up the control unit enclosure and fit the cover of the hybrid manager.
- ▶ Fit caps to the shut-off valves on the pipe work for liquid and gaseous refrigerant.

**11.2 REMOVING THE CASING FROM THE EXTERNAL UNIT**

To remove the service cover, top, front and rear parts, proceed as follows:

- ▶ Remove 3 screws (M 10x4) from the top section of casing [1].
- ▶ Remove top section [1].
- ▶ Remove screw (M 10x4) from service cover [3].
- ▶ Pull service cover [3] forward and remove.
- ▶ Remove 9 screws (M 10x4) from the front section of cover [4].
- ▶ Remove front section [4].
- ▶ Remove 7 screws (M 10x4) from the rear section of casing [2].
- ▶ Remove rear section [2].





Fig. 73 Removing casing from the external unit

**11.3 REPLACING THE FAN MOTOR**

- ▶ Removing the top section of the casing
- ▶ Remove front casing panel.
- ▶ Remove nut (M 6, left-hand thread).
- ▶ Remove impeller.

**CAUTION:** Damage through electrostatic discharge!  
▶ Never touch a PCB without an earthed wristband.

- ▶ Pull plug CNF1 off the PCB inside the electronics casing (→ Fig. 81, page 87).
- ▶ Undo fixing for connecting cable on motor bracket.
- ▶ Remove 4 screws (M 4 x 18) and remove the fan motor.




6 720 646 970-122.3ITL

Fig. 74 Replacing the fan motor


- [1] Fan motor
- [2] Evaporator
- [3] Enclosure for electric components
- [4] Temperature sensor TH8
- [5] Power circuit board
- [6] Controller circuit board
- [7] Noise circuit board
- [8] Temperature sensor TH7
- [9] Temperature sensor TH6
- [10] Temperature sensor TH4
- [11] Temperature sensor TH32
- [12] Linear expansion valve LEV-B
- [13] Linear expansion valve LEV-A
- [14] Temperature sensor TH3
- [15] Temperature sensor TH33
- [14] Nut
- [15] Impeller

## 11.4 REPLACING THE PCB HOUSING



- ▶ Remove service cover (→ Fig. 73, page 77).
- ▶ Remove top casing panel.
- ▶ Remove front casing panel.
- ▶ Pull BUS cable plug to the hybrid manager at the terminal strip (TB1).
- ▶ Pull the following plugs at the PCB (→ Fig. 74, page 78 and Fig. 81, page 87).
  - Fan motor (CNF1)
  - Linear expansion valves (LEV-A and LEV-B)
  - Temperature sensors TH3, TH33 on the pipe work for liquid refrigerant
  - Temperature sensor TH32 on compressor casing
  - Temperature sensor TH4 for hot gas
  - Temperature sensor TH6 for evaporator (2-phase cable) and outside temperature sensor TH7
  - High pressure switch (63H)
  - 4-way valve
- ▶ Remove disconnected cables from electronics casing.
- ▶ Pull compressor plug.
- ▶ Remove 3 fixing screws from electronics casing.
- ▶ Remove electronics casing by lifting it clear.

## 11.5 REPLACING PCBs



### 11.5.1 NOISE CIRCUIT BOARD

- ▶ Undo all connectors.
- ▶ Undo suppression filter (→ Fig. 74, page 78) from the plastic retainers and remove.

### 11.5.2 POWER CIRCUIT BOARD

#### REMOVAL

- ▶ Undo all connectors.
- ▶ Undo 3 screws from the passive cooler.
- ▶ Undo inverter PCB (→ Fig. 74, page 78) from the plastic retainers and remove.


#### INSTALLATION

- ▶ Apply conducting paste thinly and evenly.
- ▶ Insert inverter PCB and tighten the 3 screws of the passive cooler.

### 11.5.3 CONTROLLER CIRCUIT BOARD

- ▶ Undo all connectors.
- ▶ Undo PCB (→ Fig. 74, page 78) from the plastic retainers and remove.

## 11.6 REPLACING FAULTY TEMPERATURE SENSORS TH3, TH6 OR TH33



Temperature sensors TH6 and TH7 form a single unit and must, therefore, be replaced together (→ “Replacing outside temperature sensor TH7”).

- ▶ Remove service cover (→ Fig. 73, page 77).
- ▶ Remove top casing panel.
- ▶ Remove front casing panel.
- ▶ Remove back casing panel.
- ▶ Pull plug of temperature sensor TH3 (white), TH6 (red) or TH33 (yellow) off the PCB inside the electronics casing (→ Fig. 81, page 87).
- ▶ Undo fixing of connecting cables on back of electronics casing.
- ▶ Take temperature sensor TH3, TH33 or TH6 out of its holder.

## 11.7 REPLACING OUTSIDE TEMPERATURE SENSOR TH7



**CAUTION:** Equipment damage due to electrostatic discharge!  
▶ Never touch a PCB if you are not wearing an earthed wristband.



Temperature sensors TH6 and TH7 are a single unit and must be replaced at the same time (→ “Removing outside temperature sensor TH6”).

- ▶ Remove service cover (→ Fig. 73, page 77).
- ▶ Remove top casing panel.
- ▶ Pull plug of temperature sensor TH7 (red) off the PCB inside the electronics casing (→ Fig. 81, page 87).
- ▶ Undo fixing of connecting cable on back of electronics casing.
- ▶ Take temperature sensor TH7 out of its holder.

## 11.8 REPLACING TEMPERATURE SENSORS TH4 AND TH32



**CAUTION:** Equipment damage due to electrostatic discharge!  
▶ Never touch a PCB if you are not wearing an earthed wristband.

- ▶ Remove service cover (→ Fig. 73, page 77).
- ▶ Remove top casing panel.
- ▶ Remove front casing panel.
- ▶ Remove back casing panel.
- ▶ Removing electronics casing
- ▶ Remove temperature sensor TH4 from the retainer (→ Fig. 81, page 87).
- ▶ Take temperature sensor TH32 on compressor casing out of its holder.

### 11.9 FITTING AND REMOVING THE LINEAR EXPANSION VALVE

The linear expansion valve LEV (→ Fig. 74, Page 78) comprises two components, i.e. the valve body and the electric drive. The electric drive can be replaced separately from the valve body.

**i** When fitting or removing the electric drive always ensure that you hold the valve body tightly to prevent damage to the refrigerant lines.

#### REMOVING THE ELECTRIC DRIVE

**i** Never use force to remove the electric drive. If the electric drive is difficult to remove, move it lightly to and fro until it can be removed easily.

- ▶ Hold valve body [2] tightly and remove the electric drive [1] upwards.




Fig. 75 Removing the electric drive

- ▶ Undo the drive terminal on the PCB.

#### FITTING THE ELECTRIC DRIVE

- ▶ Hold valve body [2] tightly and fit the electric drive on top so that the guide tabs [1] click into the recesses in the valve body.




Fig. 76 Fitting the electric drive

- ▶ Ensure that the electric drive is correctly locked in place and sits tightly.



Never wind the control and power cables around the valve body.

- ▶ Route cables free of stress and connect the terminal with the PCB.

### 11.10 REMOVING THE TRANSFORMER (ACL)



The transformer is in the Outdoor Unit and attached to the rear of the electrical parts box.

At the Outdoor Unit (ODU):

- ▶ Remove the service panel.
- ▶ Remove the top panel.
- ▶ Remove the front panel.
- ▶ Remove the back panel.
- ▶ Remove the four reactor fixing screws and remove the reactor.

Replace the items in the reverse order.

## 12 FILLING THE REFRIGERANT CIRCUIT



**CAUTION:** Damage from unsuitable refrigerant!

- ▶ Fill the system exclusively with R410A refrigerant.
- ▶ Never mix R410A refrigerant with other refrigerants. Never add lubricant to the system.
- ▶ Never use a charging cylinder. If a charging cylinder is used, the composition of the refrigerant will change and the efficiency will be lowered.

The refrigerant circuit is pre-charged with 2.5 kg of R410A refrigerant. This amount is adequate for a pipe run of between 0.5 and 30 m in both directions. Refrigerant only needs to be topped up if refrigerant was discharged during maintenance work.

Observe the following information if the refrigerant circuit needs to be refilled:

- ▶ Only qualified and authorised refrigeration engineers may work on the refrigerant circuit.
- ▶ Use only the specified refrigerant (R410A) to charge the refrigerant lines.
- ▶ Never allow air to remain in the lines.
- ▶ After completing service, charge the refrigerant circuit with specified amount of refrigerant.
- ▶ Never use a charging cylinder. If a charging cylinder is used, the composition of the refrigerant will change and the efficiency will be lowered.

### 12.1 EVACUATING AND DRYING THE REFRIGERANT CIRCUIT

**WARNING:** Personal injury from rupturing refrigerant pipes!  
Air bubbles trapped in lines can result in pressure peaks which can result in pipes bursting.

- ▶ Never allow air to remain in the lines.

**i** The external unit is pre-charged with 2.5 kg of R410A refrigerant. Commissioning does not require topping up with refrigerant.

Remove air from the refrigerant circuit by the correct vacuum drying process. In the case of inadequate vacuum drying air and water vapours remain in the refrigerant circuit. These may result in an abnormal rise in positive pressure or in a drop in negative pressure as well as to a loss of quality in the refrigerant oil through moisture. This may have a negative effect on the compressor service life.

### 12.2 VACUUM DRYING

**i** Never use the refrigerant from the external unit to purge air from the refrigerant lines.

- ▶ Connect a high performance vacuum pump to the Schrader valve (→ Fig. 77, [1]).
- ▶ With the vacuum pump build a pressure of 101 kPa(g) (5 Torr).
- ▶ Maintain this pressure **for at least 1 hour**.
  - During this time check the vacuum pressure constantly at the pressure gauge.
  - If the vacuum pump is only used for a short time, it may not be possible to bring about a complete evacuation. In addition it may result in moisture remaining in the pipe work.
- ▶ Switch off the vacuum pump and close the distributor valve.
- ▶ Observe the pressure for 15 minutes.  
Should the pressure rise during that time (vacuum reduces), evacuate and repeat the final test.
- ▶ Separate the vacuum pump from the refrigerant circuit.

### 12.3 OPENING THE SHUT-OFF VALVES OF THE EXTERNAL UNIT

**NOTICE:** Damage from closed shut-off valves!  
Compressor and control valves will suffer damage if the shut-off valves remain shut during the operation of the external unit.

- ▶ Open shut-off valves for liquid and gaseous refrigerant.

Open the shut-off valves on the liquid and gaseous refrigerant pipe work:

- ▶ Remove valve cap [2].
- ▶ With an Allen key (4 mm) turn the valve head [3] anti-clockwise as far as it will go (approx. 10 turns).  
Stop turning once the end-stop has been reached.
- ▶ Turn valve head [3] ½ one turn back (clockwise).
- ▶ Attach valve cap [2]. When doing this ensure that the inside remains undamaged as this serves as a sealing face.
- ▶ Tighten valve cap [2] with a torque of between 20 and 25 Nm.  
Failure to replace and tighten the caps may result in refrigerant leakage.




Fig. 77 Shut-off valve on the liquid refrigerant pipe work

- [1] Schrader valve
- [2] Valve cap
- [3] Valve head
- [4] Pipe work to building
- [5] Pipe work to the external unit

### 13 APPENDIX

#### 13.1 COST WEIGHTING ELECTRICITY PRICE – GAS PRICE

		Electricity price [P/kWh]																				
		10.0-10.9	11.0-11.9	12.0-12.9	13.0-13.9	14.0-14.9	15.0-15.9	16.0-16.9	17.0-17.9	18.0-18.9	19.0-19.9	20.0-20.9	21.0-21.9	22.0-22.9	23.0-23.9	24.0-24.9	25.0-25.9	26.0-26.9	27.0-27.9	28.0-28.9	29.0-29.9	30.0-30.9
Gas price [P/kWh]	3.0-3.9	2.8	3.0	3.3	3.5	3.8	4.1	4.3	4.6	4.9	5.1	5.4	5.7	5.9	6.2	6.4	6.7	7.7	7.2	7.5	7.8	8.8
	4.0-4.9	2.1	2.3	2.5	2.7	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4	4.6	4.8	5.0	5.2	5.4	5.6	5.8	6.0	6.2
	5.0-5.9	1.7	1.9	2.1	2.2	2.4	2.6	2.7	2.9	3.1	3.2	3.4	3.6	3.7	3.9	4.1	4.2	4.4	4.6	4.7	4.9	5.1
	6.0-6.9	1.5	1.6	1.8	1.9	2.0	2.2	2.3	2.5	2.6	2.7	2.9	3.0	3.2	3.3	3.4	3.6	3.7	3.9	4.0	4.2	4.3
	7.0-7.9	1.3	1.4	1.5	1.6	1.8	1.9	2.0	2.1	2.3	2.4	2.5	2.6	2.7	2.9	3.0	3.1	3.2	3.3	3.5	3.6	3.7
	8.0-8.9	1.1	1.2	1.3	1.4	1.6	1.7	1.8	1.9	2.0	2.1	2.2	2.3	2.4	2.5	2.6	2.7	2.8	3.0	3.1	3.2	3.3
	9.0-9.9	1.0	1.1	1.2	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2.0	2.1	2.2	2.3	2.4	2.4	2.5	2.6	2.7	2.8	2.9
	10.0-10.9	0.9	0.9	1.1	1.2	1.3	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2.0	2.0	2.1	2.2	2.3	2.4	2.5	2.6	2.6
	11.0-11.9	0.8	0.9	1.0	1.1	1.1	1.2	1.3	1.4	1.5	1.5	1.6	1.7	1.8	1.9	1.9	2.0	2.1	2.2	2.3	2.3	2.4
	12.0-12.9	0.8	0.8	0.9	1.0	1.1	1.1	1.2	1.3	1.3	1.4	1.3	1.6	1.6	1.7	1.8	1.9	1.9	2.0	2.1	2.2	2.2
	13.0-13.9	0.7	0.8	0.8	0.9	1.0	1.0	1.1	1.2	1.2	1.3	1.2	1.4	1.5	1.6	1.7	1.7	1.8	1.9	1.9	2.0	2.1
	14.0-14.9	0.7	0.7	0.8	0.8	0.9	1.0	1.0	1.1	1.2	1.2	1.2	1.3	1.4	1.5	1.5	1.6	1.7	1.7	1.8	1.9	1.9
	15.0-15.9	0.6	0.7	0.7	0.8	0.9	0.9	1,	1.0	1.1	1.1	1.1	1.3	1.3	1.4	1.4	1.5	1.6	1.6	1.7	1.7	1.8
16.0-16.9	0.6	0.6	0.7	0.7	0.8	0.9	0.9	1.0	1.0	1.1	1.0	1.2	1.2	1.3	1.4	1.4	1.5	1.5	1.6	1.6	1.7	

Table 47 Example: Cost weighting electricity price – gas price

**13.2 SYSTEM WIRING (HEATRONIC III BOILER CONNECTIONS) WITH A BYPASS VALVE AND ONE UNMIXED HEATING CIRCUIT**




Fig. 78 Wiring example

- [A] 4-core wiring
- [B] 2-core wiring
- [C] 3-core wiring
- [1] Outside temperature sensor (fitted on north facing wall)
- [2] ISM1
- [3] Interconnecting cables between hybrid manager and air to water heat pump
- [4] Connections, air to water heat pump
- [5] Connections, hybrid manager
- [6] Temperature sensor (condenser outlet)
- [7] Temperature sensor (condenser inlet)
- [8] Heating circuit
- [9] Automatic by-pass valve
- [10] Buffer tank
- [11] FW200 control unit
- [12] Expansion vessel
- [13] WHM hybrid manager (internal unit)
- [14] Boiler
- [15] Heatronic III boiler connections
- [16] DHW cylinder
- [17] Cylinder pump
- [18] External unit
- [19] Temperature sensor, refrigerant
- [20] PSS1 solar circuit pump

**13.3 SYSTEM WIRING (CUS BOILER CONNECTIONS) WITH A BYPASS VALVE AND ONE UNMIXED HEATING CIRCUIT**




Fig. 79 Wiring example

- [A] 4-core wiring
- [B] 2-core wiring
- [C] 3-core wiring
- [1] Outside temperature sensor (fitted on north facing wall)
- [2] ISM1
- [3] Interconnecting cables between hybrid manager and air to water heat pump
- [4] Connections, air to water heat pump
- [5] Connections, hybrid manager
- [6] Temperature sensor (condenser outlet)
- [7] Temperature sensor (condenser inlet)
- [8] Heating circuit
- [9] Automatic by-pass valve
- [10] Buffer tank
- [11] FW200 control unit
- [12] Expansion vessel
- [13] WHM hybrid manager (internal unit)
- [14] Boiler
- [16] DHW cylinder
- [17] Cylinder pump
- [18] External unit
- [19] Temperature sensor, refrigerant
- [20] PSS1 solar circuit pump
- [21] CUS boiler connection

6720803887-30.1W6

**13.4 WIRING TO PCB IN THE EXTERNAL UNIT (HEAT PUMP)**




Fig. 80 Wiring to PCB in the external unit

- [1] M-NET adaptor (not installed)
- [2] Hybrid manager (internal unit)
- [3] Supply voltage 230 V, 50 Hz
- [4] SW5-1 to 5: function switches

<b>Symbol</b>	<b>Description</b>	<b>Symbol</b>	<b>Description</b>
<b>TB1</b>	Terminal strip (supply voltage for internal and external unit)	<b>C. B</b>	Printed circuit board (PCB)
MC	Compressor motor	FUSE1-4	Fuse (6.3 A)
MF1, MF2	Fan motor 1 and 2	SW1	DIP switch – settings
21S4	4-way valve	SW4	DIP switch – test mode
63H	High pressure switch	SW5	DIP switch – function selection
63L	Low pressure switch	SW7	DIP switch – function selection
SV	Bypass solenoid valve	SW8	DIP switch – switch
TH3	Temperature sensor (liquid)	J1-6	Jumper, module selection
TH4	Temperature sensor (hot gas)	SWP	Pump empty switch
TH6	Temperature sensor (evaporator/condenser)	CN31	Emergency mode plug
TH7	Temperature sensor (outside air)	LED1, 3	LED operating status
TH8	Temperature sensor (inverter)	LED5, 6	LED motor status
LEV-A, LEV-B	Expansion valves	CNAC	Plug
DCL1, DCL2	DC link coil	CNDC	
ACL	Reactor	CNS	
52C	Contactor	FAN11	Fan motor plug
RS	Voltage peak protection	FAN12	
ACTM	Filter module	FAN21	
CE	Trimmer	FAN22	
		SS	Plug options
<b>P. B</b>	Power supply circuit board	SV2	Plug
R/S	Terminals (L/N)	CNM	Plug for A-Control service tool
SC-R/S	Screw terminals (L/N)	CNMNT	Plug for M-NET adapter
SC-P1, P2	DC voltage screw terminals	CNVMNT	Plug for M-NET adapter
SC-N1, N2	DC voltage screw terminals	CNDM	Plug for external signals
U/V/W	Terminals (U/V/W)	X51, 52, 54	Relays
CN2-5	Plug	FET1	Motor drive, servo amplifier
PFC	Converter		
IPM	Inverter	<b>N. F</b>	Interference suppressor
CB1-3	Trimmer	LI/LO	L-phase terminals
CNDC	Plug	NI/NO	N-phase terminals
CNAF		E, EI	Earth terminals
IGBT	Inverter	CNAC 1/2	Plug
LED1	LED, inverter status	CN5	
		CN52C	
		52C	Contactor

*Table 48 Key to wiring diagram*

13.5 CONTROLLER CIRCUIT BOARD IN EXTERNAL UNIT




Fig. 81 Power circuit board (see following page for key)

No.	Symbol	Description
1	DNDM	1-2: Quiet running input (unavailable on this model) 1-3: External signal input
2	CN51	External output signals (compressor operation signal, fault displays)
3	CN52C	Connection to interference suppressor
4	CN4	Control signals to inverter board
5	SV2	Bypass valve
6	21S4	4-way valve
7	CN2	Connection to power circuit board of external unit 1-5: control signals to the PCB (0–5 V DC) 2-5: Zero-cross signal (0–5 V DC) 3-4: Not used 6-5: 16 V DC 7-5: 16 V DC
8	CNAC	2-4: PCB power supply (220–240 V AC) 1-3: power supply from the control cable to the hybrid manager (220–240 V AC)
9	CNS	S1-S2: 220–240 V AC
10	+/-	Supply voltage for communication D71 V, voltage 24 V DC
11	CNDC	280 V DC (inverter board 140 V)
12	CNF1, CNF2	Connection for fan motors 1-4: 280 V DC 5-4: 15 V DC 6-4: 0–6.5 V DC 7-4: 15 V DC at idle, 7.5 V DC during rotation, 0–15 V pulsed
13	V <sub>SP</sub>	Voltage of pins on C5A, C5B: 0 V DC at idle, 1.5 V DC during rotation
14	V <sub>FG</sub>	Voltage between the right-hand pins on PC5C and PC5D, pin 3 and pin 4 (same as CNF1)
15	TH33	Temperature sensor (liquid line)
16	TH32	Temperature sensor (compressor casing)
17	63H	High pressure switch
18	TH7/6	Temperature sensor (heat exchanger, 2-phase mixture)
19	TH3	Temperature sensor (liquid line)
20	TH4	Temperature sensor (hot gas)
21	LEV-A, LEV-B	Linear expansion valves
22	CNVMNT	M-NET adapter (optional)
23	CNMNT	M-NET adapter (optional)
24	CNM	A-Control service tool
25	SW8	
26	SW5	Function switch
27	SWP	Pump back mode
28	SW4	Test mode
29	SW6	Model selection
30	SW1	Forced defrost mode, delete fault list, appliance address
31	SW7	Step control

*Table 49 Key to inverter PCB*

### 13.6 ALTERNATIVE PIPE WORK LENGTHS AND $\Delta T$

Additional pipe length [m]	Maximum flow rate [l/min]	Heating output [kW]	$\Delta T$ [K]	Residual pressure [mbar]
20	15.3	21.86	20	200
10	16.3	23.29	20	200
6	16.8	24.00	20	200
0	17.6	25.14	20	200
20	15.3	23.96	21.5	200
10	16.3	25.03	21.5	200
6	16.8	25.80	21.5	200
0	17.6	27.03	21.5	200

Table 50 : Alternative  $\Delta T$  between the heating system flow and return based on additional pipe length

Heating output [kW]	Additional pipe length [m]	Maximum flow rate [l/min]	$\Delta T$ [K]
28	20	15.3	25.62
30			27.45
28	10	16.3	24.05
30			25.77
28	6	16.8	23.33
30			25.00
28	0	17.6	22.27
30			23.86

Table 51 : Alternative  $\Delta T$  between the heating system flow and return based on heating output



The maximum length of refrigerant pipework must be maximum 30m each way and therefore must be taken into account when extending CH system pipework.

**14 GENERAL DETAILS**

<b>CLIENT / HEATING CONTRACTOR</b>			
Name:		Commission number:	
Street / House number:		Postcode / Town:	
Telephone:		Fax:	
Mobile:		Email:	
<b>COMMISSIONING</b>			
<input type="checkbox"/> Initial comm	<input type="checkbox"/> Repeat comm	<input type="checkbox"/> Comm terminated	
<b>SYSTEM LOCATION</b>			
Name:		Street:	
Postcode:		Town:	
<b>HEATING INSTALLATION</b>			
Name:		Street:	
Postcode:		Town:	
<b>ELECTRICAL INSTALLATION</b>			
Name:		Street:	
Postcode:		Town:	

Table 52 General details

<b>APPLIANCE AND ACCESSORY (to be completed by installer)</b>		
The following was/were installed	<input type="checkbox"/> Hybrid Manager   <input type="checkbox"/> External unit   <input type="checkbox"/> Control unit	
Usage	<input type="checkbox"/> Private   <input type="checkbox"/> Office   <input type="checkbox"/> Other:	
<b>Designation</b>	<b>Appliance type</b>	<b>Serial number / Software version</b>
Hybrid Manager (internal unit)		
External unit		
Heat appliance		

Table 53 Installed appliance and accessory

<b>APPLIANCE AND ACCESSORY (to be completed by installer)</b>		
Control system		
Hybrid control module		
Bypass valve		

*Table 53 Installed appliance and accessory*



<ul style="list-style-type: none"> <li>• Pipework length of heating system</li> <li>• Total pipework pressure drop</li> <li>• Installation room volume (min. 5.7 m<sup>3</sup>)</li> </ul>	<p>_____ m</p> <p>_____ bar</p> <p>_____ m<sup>3</sup></p>
<p>Additional components installed</p> <ul style="list-style-type: none"> <li>• Bypass valve</li> <li>• Expansion vessel, capacity, pre-charge pressure</li> </ul>	<p><input type="checkbox"/> Yes   <input type="checkbox"/> No</p> <p>_____ l</p>
Pipes insulated correctly	<input type="checkbox"/> Yes   <input type="checkbox"/> No
<p>Buffer tank</p> <p>Buffer cylinder connected in accordance with the hydraulic diagram</p>	<p><input type="checkbox"/> Yes  </p> <p>Capacity: _____ l</p> <p><input type="checkbox"/> Yes   <input type="checkbox"/> No</p>
<p>Domestic hot water heating (DHW) with Hybrid Split</p> <p>DHW cylinder</p>	<p><input type="checkbox"/> Yes   <input type="checkbox"/> No</p> <p><input type="checkbox"/> Yes   <input type="checkbox"/> No</p> <p>Capacity: _____ l</p> <p>Heat exchanger surface: _____ m<sup>2</sup></p>
Number of mixed heating circuits:	Number of unmixed heating circuits:
Heat distributor	<p><input type="checkbox"/> Radiators   <input type="checkbox"/> Underfloor heating system</p> <p><input type="checkbox"/> Other</p>
Primary circuit is properly installed, filled, vented and checked for tightness	<input type="checkbox"/> Yes   <input type="checkbox"/> No
Hydraulic balancing been done	<input type="checkbox"/> Yes   <input type="checkbox"/> No

Table 54 Assembly and installation report

	<p><b>NOTICE:</b></p> <p>► Check filter valve after commissioning for debris and clean filter.</p>
--	--

## 16 COMMISSIONING REPORT FOR THE COMMISSIONING ENGINEER

The commissioning report will be completed and signed by the commissioning engineer.

Action	Confirmation / values
Refrigerant lines connected, insulated and tightness of the refrigerant circuit checked.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
Power supply established and BUS cable connected to the external unit.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
DIP switches of the external unit set and checked.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
The power supply to the external unit has been 'live' for at least 12 hours prior to commissioning the overall system.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
Heating system filled with water and pressure checked. • Expansion vessel supply pressure • Heating system charge pressure	<input type="checkbox"/> Yes   <input type="checkbox"/> No Value: _____ bar Value: _____ bar
Power supply to the external unit isolated, BUS cable connected to the hybrid Manager (internal unit).	<input type="checkbox"/> Yes   <input type="checkbox"/> No
Overall system switched on.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
FW200 programming unit connected to the Hybrid Manager.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
Heating pump set up in the heat appliance.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
FW200 programming unit configured in accordance with the system set up (→ separate operating instructions).	<input type="checkbox"/> Yes   <input type="checkbox"/> No
High efficiency pump in the Hybrid Manager (internal unit) set up.	<input type="checkbox"/> Speed stage I <input type="checkbox"/> Speed stage II <input type="checkbox"/> Speed stage III $\Delta T = \_\_\_ K$ ; heating output = $\_\_\_ kW$
Vented.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
Bypass valve set up.	Value: _____

Table 55 Commissioning report for the commissioning engineer

Action	Confirmation / values
Parameters set. • Boiler / air to water heat pump switched subject to:  • Energy price ratio of electricity / fossil fuel  • What is the primary energy factor for the fossil fuel?  • What is the primary energy factor for electricity?  • What should the dual mode switching threshold be?	<input type="checkbox"/> Yes   <input type="checkbox"/> No <input type="checkbox"/> Cost-optimised <input type="checkbox"/> Environmental factors <input type="checkbox"/> Environment and costs <input type="checkbox"/> Changeover threshold  Setting value: _____  Setting value: _____  Setting value: _____  Setting value: _____
All casing parts fitted.	<input type="checkbox"/> Yes   <input type="checkbox"/> No
User instructed and technical documentation handed over.	<input type="checkbox"/> Yes   <input type="checkbox"/> No

Table 56 Commissioning report for the commissioning engineer

<b>Commissioning and handover of the heat pump by the commissioning engineer:</b>			
<input type="checkbox"/> Commissioning completed successfully.		<input type="checkbox"/> Commissioning terminated; follow-up date required.	
<input type="checkbox"/> User instructed.		<input type="checkbox"/> Commissioning completed, faults noted under "Comments" must be removed. <sup>1)</sup>	
<input type="checkbox"/> Faults removed on the:		Client signature:	
<b><sup>1)</sup> The faults recorded in the commissioning report must be actioned with out delay.</b>			
Company:		Service engineer:	
Street:		Postcode / Town:	
Telephone:		Fax:	
Date:		Signature Commissioning engineer:	
Date:		Signature Client/user:	
<b>ATTACHMENTS</b>			
		<input type="checkbox"/> Hydraulic diagram	
		<input type="checkbox"/> Electrical connection diagram	
		Miscellaneous:	

Table 57 Commissioning report - handover







# Service Record

It is recommended that your heating system is serviced regularly and that the appropriate Service Interval Record is completed.

## Service Provider

Before completing the appropriate Service Interval Record below, please ensure you have carried out the service as described in the manufacturer's instructions.

Always use the manufacturer's specified spare part when replacing controls.

### Service 1

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 2

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 3

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 4

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 5

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 6

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 7

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 8

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 9

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

### Service 10

Date: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Telephone No. \_\_\_\_\_

Operative ID No. \_\_\_\_\_

Comments: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Signature: \_\_\_\_\_

Worcester, Bosch Group  
Cotswold Way, Warndon, Worcester WR4 9SW.  
Tel. 0844 892 9900

Worcester, Bosch Group is a brand name of Bosch Thermotechnology Ltd.  
[worcester-bosch.co.uk](http://worcester-bosch.co.uk)

6 720 803 687 (2012/11)

**WORCESTER, BOSCH GROUP:**

TECHNICAL SUPPORT: 0844 892 3366  
APPOINTMENTS: 0844 892 3000  
SPARES: 01905 752571  
LITERATURE: 0844 892 9800  
TRAINING: 01905 752526  
SALES: 01905 752640

The logo for Worcester Bosch Group features a stylized, wavy graphic element on the left, composed of three overlapping, curved lines in shades of grey. To the right of this graphic, the word "WORCESTER" is written in a large, bold, black, sans-serif font. Below "WORCESTER", the words "Bosch Group" are written in a smaller, bold, black, sans-serif font.

**WORCESTER**  
**Bosch Group**